



Stages™ | K-6231

Flip Tray for Stages 33" and 45" Sinks

Features

- Fits atop the accessory ledge of the K-3760 and K-3761 Stages kitchen sinks
- Included with the K-3760 and K-3761 Stages kitchen sinks
- Versatile tray can either contain items or be flipped to act as a cutting board
- Durable plastic construction
- Dishwasher-safe



Available Colors/Finishes

Color tiles intended for reference only.

- 0 White



1-800-4KOHLER (1-800-456-4537)
Kohler Co. reserves the right to make revisions without notice to product specifications.
For the most current specification sheet, go to www.kohler.com USA or www.kohler.ca Canada.
3-27-2026 18:48 - US-CA

THE BOLD LOOK
OF **KOHLER**®

Codes/Standards

None Applicable

Recommended Products/Accessories


K-23723 Faucet cleaner

Warranty

See website for detailed warranty information.

KOHLER® One-Year Limited Warranty





Installation Notes

Install this product according to the installation instructions.

