

QUICK START GUIDE

Please take a few moments to read this Quick Start Guide. It is designed to help you assemble your vacuum easily.

To view our "How to Assemble" demo, visit www.eureka.com/airspeed/assembly

If you have questions about your new vacuum, please contact our customer service helpline at 1-800-282-2886. We're here to help!

Helpline Hours: 8 a.m. to 7:30 p.m. (CST), Monday - Friday 10 a.m. to 6:30 p.m. (CST), Saturday - Sunday





What's in the carton

No screws or tools required!




Vacuum cleaner

OWNER'S GUIDE REGISTRATION Important Safeguards



Handle




Carry handle






Turbo holder

PLEASE READ ALL INSTRUCTIONS BEFORE USING THIS VACUUM CLEANER.



Lower hose







Follow

in order


to ensure

assembly.


proper

1-12


Easy assembly




Remove dust cup.




Place handle on vacuum; push down to snap in place.




Slide carry handle into back of handle. Snap into place.




Insert top tab of turbo holder into handle. Place thumbs on each side and snap bottom corners into place. Turn knob to lock.



Place lower hose retainer in slots on back of vacuum. Push down past rib.




Place upper hose retainer on back of handle. Push up to snap into place.




To install hose connector. align tab at right and snap on at left.




Pull out bottom of lower hose retainer and position hose.



Place hose over upper hose retainer.



Push A onto end of hose: slide **B** over **A**. Place over bottom hook; snap in at top.



Push cord into carry handle and upper cord retainer. Wrap cord.



Place dust cup on vacuum. Push back to latch.




Get ready to vacuum


Power switch is marked (I) for on-off.



To vacuum floors, turn air path knob to 'floors.'




Adjust height for carpet or bare floors.



Step on power switch to turn on; step on again to turn off.



Step on handle release to lower handle into position.



Attach tool to end of wand. Turn air path knob to 'tools.' Store tools on carry handle and turbo nozzle in holder.




Clean and assemble dust cup

Empty dust cup after each use.




Pull back latch to lift off lid.



For quick clean: tap filter. To clean thoroughly: grasp filter and twist to remove from lid. Brush off debris.



Remove screen. Rinse screen, filter and dust cup. Dry thoroughly.



Align tab with slot to reinstall screen. Grasp filter and twist in lid to reinstall. Align lid at front; press down until lid snaps.