
Item Number: A04976C3

WARNING (To reduce the risk of fire, electric shock, or personal injury):


- 1. We suggest installation by a licensed electrician.
- 2. Please read the instruction carefully and save it as you may need it at a later time.
- 3. Before you start, **NEVER** attempt any work without shutting off the electricity until the work is done.
 - So to the main fuse, or circuit breaker, box in your home. Place the main power switch in the "OFF" position.
 - » Place the wall switch in the "OFF" position.
- 4. Mounting surface should be clean, dry, flat, strong enough and 1/4" larger than the canopy on all sides. Any gaps between the mounting surface and canopy exceeding 3/16" should be corrected as required.
- 5. Make sure that the ceiling or wall can stand the weight of the lamp before installation.
- 6. Make sure the voltage you are using is 120V. The maximum wattage is Type G, Max 40W per bulb.
- 7. Keep the lamp away from acidic and alkaline substances in case of damaging the surface of the lamp.
- 8. When replacing bulbs, you should turn off or unplug the lamp and you must wait until it is cool as bulbs get hot quickly.
- 9. The safety instructions appearing in this manual are not meant to cover all possible conditions that may occur. It must be understood that common sense, caution and care must be used with any electrical products.

IMAGE FOR FINISHED PRODUCT:




TOOLS REQUIRED (NOT INCLUDED):

Before starting assembly and installation please prepare the needed tools as below picture



PARTS TYPE & QTY INCLUDED:

- (C) Green ground screw (1)
- (D) Mounting plate (1)
- (E) Canopy (1)
- (F) Loop (4)
- (G) Quick link (2)
- (H) Knob nut (2)
- (I) Stem
- (J) Iron frame (1)
- (K) Tube (3)
- (L) Socket (3)
- (M) Lampshade (3)
- (N) Socket ring (3)




ACCESSORIES & QTY ENCLOSED:

- (A) Mounting screw (2)
- (B) Plastic wire connector (3)

ASSEMBLY & INSTALLATION INSTRUCTIONS:

1. Carefully remove the fixture from the carton and check that all parts and accessories are included as shown in the above illustration.

2. Make pre-installation




- Step A1 » Connect stems (I) and then screw stems (I) and tubes (K) into iron frame (J) as shown in the illustration.
 - The connecting stems (I) are detachable. The length of the light can be decided according to your preference.
- Step A2 » Attach quick links (G) to the loops (F) of canopy (E) and the loop(F) of stems (I) to connect them as shown in the illustration.

3. Turn off power

Before you start the installation, NEVER attempt any work without shutting off the electricity until the work is done.

- **»** Go to the main fuse, or circuit breaker, box in your home. Place the main power switch in the "**OFF**" position.
- » Place the wall switch in the "OFF" position.

4. Make installation



Step B1 » Unscrew knob nuts (H) from mounting plate (D) and then remove mounting plate (D) from canopy (E).

Step B2 » Attach mounting plate (D) to the outlet box with mounting screws (A).

Step B3 » Make wire connections

Connect wires as shown in the charts below. PLEASE NOTE THAT GROUND WIRE IS BARE COPPER WIRE, NEVER CONNECT OTHER WIRES TO GROUND WIRES.

Connect ground wires according to the chart below Connect wires according to the chart below Connect Black or Connect В Red Supply Wire to: White Supply Wire to: Black **OUTLET BOX OUTLET BOX** GROUND GROUND *Parallel cord (round & smooth) FIXTURE Clear, Brown, Gold or Black without GROUND Insulated wire(other than green) CUPPED WASHER DIMPLES GREEN GROUND GREEN GROUND SCREW **Neutral Wire** SCRFW White *Parallel cord (square ridged) Twist wires together with plastic wire connectors until tightlyjoined. Wrap each connector with approved electrical tape. Clear, Brown, Gold or Black with

* Note: When parallel wires (SPT I& SPT II) are used. The neutral wire is square shaped or ridged and the other wire will be round in shape or Step B4 * Raise canopy (E) to the ceiling and secure canopy (E) en iplace by tightening knob nuts (H) onto pre-assembled screws on mounting plate (D).

NOTE: canopy (E) should be snug against the ceiling with knob nuts (H). If not, remove canopy (E), adjust the threaded length of pre-assembled mounting screws on mounting plate assembly (D):

• Be sure that no wire strands are exposed and then carefully tuck all wires into the

- First, unscrew the pre-assembled hex nuts.
- Then, screw the pre-assembled mounting screws in or out of mounting plate (D).
- When the secure length is achieved, tighten the pre-assembled hex nuts and back to Step B5.
- Step B5 » 1) Remove socket rings (N) from sockets (L).

outlet box.

- 2) Place Lampshades (M) on sockets (L) and secure them with socket rings (N).
- When installing socket rings (N), the orientation of socket rings (N) is that the side of rolled edge faces upward.
- 3) Install bulbs (not included) (Please do not exceed the maximum wattage recommended on the socket.)

5. Check that everything is installed properly, then you can turn on the light. We hope you enjoy your new lighting!

ORDERING PARTS

Keep this sheet for future reference in case you need to order replacement parts. All parts for this fixture can be ordered from the place of purchase. Be sure to use exact wording from illustration when ordering parts.

CLEANING

To clean, wipe the fixture with a soft cloth. Do not use abrasive materials such as scouring pads or powders, steel wool or abrasive paper.

Insulated wire(other than green) with silver conductor