

ASSEMBLY INSTRUCTION FOR ITEM C8363TUBS

We believe you will absolutely love your new furniture. Please immediately examine this product carefully. Any request for missing part or damage replacement must be received within 90 days of your receipt of the product. For some reason you want to return the product, please contact us directly before you decide to return your product to the retailer. Our Customer Service team can answer most concerns and can assist you with any questions you may have about your new product.

Please contact us first by emailing service@casepiece.com

Have these ready when you email:

- **Item Number**
- **PO #**
- **Purchaser Name**
- **Proof of Purchase**
- **Description of the problem and/or the Part Number needed**

Replacements for missing or damaged parts or hardware are normally shipped within 3 to 5 business days and we thank you for your patient.

The item must be returned in good condition, in original box, with all original proof of purchase, parts and accessories, within the time frame specified by the retailer it was purchased from.

90-Day Limited Warranty Statement for Manufacturing Defects

Please read this Limited Warranty carefully. To maintain your Warranty, you will need to comply with the conditions stated here. This warranty is for manufacturing defects only and does not cover damages as a result of misuse.

1. Our products sold comply with the description contained in this Warranty. All parts and products are warranted 90-Day from the original date of delivery except: parts and products used for commercial, contract, rental trade, institutional, or any other non-residential purposes; parts and products that have not been maintained in accordance with the care recommendations provided; parts and products damaged resulting from the consumer's improper assembly; or parts and products that are damaged or defective due to normal wear and tear.

2. To exercise rights under this warranty, proper documentation, i.e., photography, purchase order number, manufacturer's bar code label, and or any other pertinent information upon request is required. We reserve the right to repair or replace the product within the warranty period based upon the documentation received as support of a claim for consideration. We will not replace or repair any product if improper maintenance, improper handling, or improper use caused the damage. Any product sold from or modified by a Non-Authorized Dealer, Seller or Consumer will void the Warranty.








3. Cost of packaging and shipping to and from us is not covered by the warranty unless expressly arranged by us. This warranty does not extend to furniture that has been exchanged or replaced by us as settlement of an original claim of defective merchandise. This warranty does not extend to furniture that has been moved from delivery location on original purchase order.

We appreciate your business!

ASSEMBLY INSTRUCTION


ITEM : C8363TUBS

PARTLIST

1 	2 	5 	6 	7 
HEADBOARD CUSHION x1	HEADBOARD LEG x2	SIDE RAIL x2	SIDE RAIL x2	FOOTBOARD x1
8 	9 	13 	14 	15 
SIDE RAIL LEG x2	SLAT x4	DRAWER FRONT PANEL x1	DRAWER BACK PANEL x1	DRAWER SIDE PANEL x2
16 	17 	18 		
DRAWER SUPPORT x2	DRAWER PANEL x1	CASTOR x4		

*All parts needed are shown in above picture.
Numbers only indicate the specific parts for easy assembly.


ASSEMBLY INSTRUCTION

HARDWARE			
A  JCBB SCREW M8 x 50MM x4	B  JCBC SCREW M6 x 15MM x8	C  JCBC SCREW M6 x 20MM x16	D  SPRING WASHER M8 x 13MM x4
E  FLAT WASHER M8 x 22MM x4	F  WOOD DOWEL M6 x 30MM x16	G  MINIFIX CAM LOCK x8	H  MINIFIX BOLT x8
I  CSK C/B SCREW M4 x 16MM x16	J  L - KEY M5 x 65MM x1	K  L - KEY M4 x 100MM x1	


ASSEMBLY INSTRUCTION

STEP 1


Open zipper to get all other parts.




STEP 2



STEP 3




STEP 4




ASSEMBLY INSTRUCTION


STEP 5




STEP 6



STEP 7



STEP 8



STEP 9

The diagram illustrates the final assembly step. A vertical panel (14) is being attached to a base plate (15). Red arrows indicate the downward movement of the panel. A circular inset shows a close-up of the panel's bottom edge being secured to the base plate. Another circular inset shows a screwdriver being used to tighten a screw (G) into the panel. A note states: "**Screwdriver is not provided".

STEP 10

Diagram illustrating the installation of the bottom panel (17) into the frame (14). A red arrow indicates the panel being pushed down into the frame. The side panel (13) is also visible.

STEP 11

The diagram illustrates the process of attaching the front panel (14) to the side panel (13). A red arrow points down to the top edge of the front panel, indicating where to align it with the side panel. A circular callout shows a close-up of the top edge of the front panel (14) being aligned with the side panel (13). Another circular callout shows a close-up of the front panel (14) being attached to the side panel (13) using a screwdriver. A red arrow indicates the direction of the screwdriver's rotation. A note states: "**Screwdriver is not provided". A third circular callout shows a close-up of the front panel (14) being attached to the side panel (13) using a screwdriver. A red arrow indicates the direction of the screwdriver's rotation. A note states: "**Screwdriver is not provided".

STEP 12

****Screwdriver is not provided**

1


18

16

CASTOR OUTLINE

ASSEMBLY INSTRUCTION

STEP 13



ASSEMBLY
COMPLETED