

TOOLS REQUIRED



Allen Wrench

(Included)



Phillips Screwdriver

(Not Included)



3 - People Recommended

ASSEMBLY RATING



EASY DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

VERSION # 20-10-21



Are you m	issing anything?	Check out our Quick Tips!
	k all parts, hardware and listed on Page 6 are r.	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Are there any	e send any replacements? y irregularities or flaws in the an send replacements!	Prep Time! Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.




Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.


BED



- · Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS



Left Headboard Right Headboard Left Footboard Right Footboard Cushion Panel **Post Post Post Post**





















Headboard Panel

Footboard Panel

Side Rail 1

Side Rail 2

Mattress Rails 1








Mattress Rails 2

Finial

Support Leg 169mm x Ø7/8"

HARDWARE



Align HB panel (#6) to HB posts (#1,2), then secure by using bolts (#A).

1

Part #1 x1pc

Part #2 x1pc

Part #6 x1pc


Hardware#A x4pcs

Hardware#1 x1pc

Note:

Do not fully tighten all bolts until assembly is complete. This will help all parts to assemble properly.

Align headboard (#5) to the



2

Part #5 x1pc Hardware #D x 2pcs Hardware #E x 2pcs Hardware #F x 4pcs Hardware #H x 4pcs

Hardware #1) x1pc


Part x1pc
Part x1pc
Part x1pc
Part x1pc
Part x1pc
Part x1pc
Part x1pc
Hardware x4pcs
Hardware x1pc


#7


#7

Align footboard panel (#7) to the FB posts (#3,4), then secure by using bolts (#C).









9



- Do not remove warning label from bed.
- Use only mattress which is 83"-84" long and 71"-72" wide. (ITEM NO:CM7420CK).
- Use only mattress which is 79"-80" long and 75"-76" wide. (ITEM NO:CM7420EK).
- Use only mattress which is 74"-75" long and 53"-54" wide. (ITEM NO:CM7420F).
- Use only mattress which is 79"-80" long and 59"-60" wide. (ITEM NO:CM7420Q).
- Do not allow horseplay or under the bed and prohibit jumping on the bed.
- Periodically check and ensure that all the omponents are in their proper position, free from damage, and that all connectors are tight.
- Do not use substitute parts, Contact the store for replacement part.
- Maximum total weight is not to exceed 600 lbs.

Keep these instructions for future reference.

ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.