
### Item Number: A04856C3

### WARNING (To reduce the risk of fire, electric shock, or personal injury):

- 1. We suggest installation by a licensed electrician.
- 2. Please read the instruction carefully and save it as you may need it at a later time.
- 3. Before you start, **NEVER** attempt any work without shutting off the electricity until the work is done.
  - » Go to the main fuse, or circuit breaker, box in your home. Place the main power switch in the "**OFF**" position.
  - » Place the wall switch in the "OFF" position.
- 4. Mounting surface should be clean, dry, flat, strong enough and 1/4" larger than the canopy on all sides. Any gaps between the mounting surface and canopy exceeding 3/16" should be corrected as required.
- 5. Make sure that the ceiling or wall can stand the weight of the lamp before installation.
- 6. Make sure the voltage you are using is 120V. The maximum wattage is Type B,Max 40W per bulb.
- 7. Keep the lamp away from acidic and alkaline substances in case of damaging the surface of the lamp.
- 8. When replacing bulbs, you should turn off or unplug the lamp and you must wait until it is cool as bulbs get hot quickly.
- 9. The safety instructions appearing in this manual are not meant to cover all possible conditions that may occur. It must be understood that common sense, caution and care must be used with any electrical products.

### **IMAGE FOR FINISHED PRODUCT:**



### **ORDERING PARTS**

Keep this sheet for future reference in case you need to order replacement parts. All parts for this fixture can be ordered from the place of purchase. Be sure to use exact wording from illustration when ordering parts.

### CLEANING

To clean, wipe the fixture with a soft cloth. Clean glass with a mild cleaner (such as mild and non-abrasive soap). Do not use abrasive materials such as scouring pads or powders, steel wool or abrasive paper.

## TOOLS REQUIRED (NOT INCLUDED):

Before starting assembly and installation please prepare the needed tools as below picture

			A CONTRACTOR	The second secon
Ladder	Philips Head or Flat Blade Screwdriver	Electrical Tape	Pliers	Wire Cutter/Stripper

### PARTS TYPE & QTY INCLUDING:


- (C) Single bar (1)
- (D) Green ground screw (1)
- (E) Canopy (1)
- (F) Hex nut (1)
- (G) Cap nut (1)
- (H) Fixture body (1)
- (I) Socket (3)
- (J) Screw (9)
- (K) Glass shade (3)

### ACCESSORIES & QTY ENCLOSED:


- (A) Plastic Wire Connector (3)
- (B) Mounting screw (2)
- (J) Screw (Spare parts) (1)


# ASSEMBLY & INSTALLATION INSTRUCTIONS:

- 1. Carefully remove the fixture from the carton and check that all parts and accessories are included as shown in the above illustration.
- 2. Turn off power Before you start the installation, NEVER attempt any work without shutting off the electricity until the work is done.
  - Go to the main fuse, or circuit breaker, box in your home.
    Place the main power switch in the "OFF" position.
  - » Place the wall switch in the "OFF" position.
- 3 » Unscrew hex nut (F) and cap nut (G) from single bar (C).




NOTE: the side of single bar (C) marked "GND"	
must face out.	





#### 5 » Make wire connections

Connect wires as below wires connection shown. *REFER TO THE FOLLOWING CHARTS, NEVER CONNECT OTHER WIRES TO GROUND WIRES.* 



- 7 » 1) Install bulbs (Not included) (Please do not exceed the maximum wattage recommended on the socket.)
  - 2) Remove screws (J) from sockets (I).
  - 3) Carefully place glass shades (K) on sockets (I).
  - 4) Secure glass shades (K) with screws (J).



K

11