



QUICK-START GUIDE

Rat Zapper *ULTRA*

HOW TO GET STARTED

Open the Battery Compartment:

The **Rat Zapper *Ultra*** battery compartment is located on the top of the unit. To open, pull the securing tab back then lift the battery compartment door. Properly install 4 “D” batteries in the battery holder and re-secure the lid to the battery compartment.

Important Information: The performance of your **Rat Zapper *Ultra*** will depend upon the:

- 1) Quality of batteries;
- 2) Amount of time your **Rat Zapper *Ultra*** is turned on;
- 3) Number of rodents killed;
- 4) Cleanliness of the **Rat Zapper *Ultra*** unit floor.

| Rating | Battery Type | Expected Results |
|--------|--|--|
| BEST | Energizer e ² Lithiums | These batteries cost more but have a much longer life than others and great performance—expect 100-plus kills and/or more than a year of battery life. |
| GOOD | Duracell Ultras with M3 Technology Energizer e ² Titaniums Or Good Quality Alkaline Batteries | These batteries provide up to 60+ kills and/or about nine months of use. |
| NO! | Heavy Duty, Super Heavy Duty, Extra Heavy Duty, Carbon Zinc, Non Alkaline, NiCad (Nickel Cadmium) or NMH Rechargeables | Not recommended for use in the Rat Zapper |

What do the green and red lights on the Rat Zapper *Ultra* mean?

GREEN LIGHT:

Battery Check - When you turn the Rat Zapper *Ultra* power switch to the ON position, the green light will blink once, then turn off. This tells you the battery quality is good and all systems are a “go”. After a short, three second delay to allow your Rat Zapper electronics to check status, if the green light does not turn on at all or there is a rapid blinking red light, replace the batteries. (See chart above for Recommended Batteries.)

RED LIGHT:

Rodent Check - The Rat Zapper *Ultra* red indicator light will blink repeatedly when you’ve killed a rodent. For a guide to what the various red and green lights signify please refer to the instructions located behind the ON/OFF switch of your Rat Zapper *Ultra*.

Baiting the Trap

Dry dog or cat food makes an excellent bait. Just slide one or two pieces all the way into the rear of the Rat Zapper. You may want to experiment, but avoid moist or wet baits that may contaminate the metal plates and cause the unit to stop operating.

INSTRUCTIONS FOR CLEANING (Remove batteries first!)

When dust, dirt or other contaminants accumulate in the **Rat Zapper Ultra**, you will need to clean the unit.

Accumulated dirt, contaminants and/or moisture may trigger a false trip, causing the red light to blink repeatedly when you turn it on.

1. Always remove the batteries before cleaning to insure safety.
2. Obtain an inexpensive, thin aluminum pan large enough in width and length to accommodate the **Rat Zapper Ultra**.
3. Fill the pan with approximately 2 inches of warm water and a small amount of liquid dish detergent. Set the **Rat Zapper Ultra** in the pan and let it soak for approximately 1 hour (to loosen debris).
4. Using a soft bristle or bottle brush, commonly found in the cookware section of your local supermarket, gently brush the bottom of your **Rat Zapper Ultra**.
5. To rinse, carefully allow a gentle stream of fresh water to flow over the cleaned bottom surface of the **Rat Zapper Ultra**. Do not spray the unit out or allow moisture to intrude into the electronics that are housed in the top of the **Rat Zapper Ultra** as this may cause the electronics to short out and impair the unit's performance.
6. After cleaning and rinsing the bottom of the **Rat Zapper Ultra** thoroughly allow the water to drain and let your **Rat Zapper Ultra** air dry completely (do not use air compressor) before putting it back into service.



Woodstream Corporation

69 North Locust Street

Lititz, PA 17543

855-5-VICTOR

www.victorpest.com

Limited 1 Year Warranty (with Proof of Purchase)

Woodstream Corporation provides a one-year parts and labor warranty that the **Rat Zapper Ultra** will be free from defects in workmanship and materials. Woodstream Corporation's obligation under this warranty shall be limited to repairing or replacing any part of the product which is defective. Service can be arranged by contacting us at **855-5-VICTOR**, **Warranty is void in the event of misuse or abuse of the product or as a result of unauthorized repairs or alterations.**