WARNING

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL. ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

CARE AND MAINTENANCE

Unplug lamps before using any cleaning solutions. Dust shades with a feather duster or with an appropriate vacuum-brush attachment. Wipe with a soft, dry cloth and clean lamp bases with the methods appropriate to the material. Avoid the use of chemicals and household cleaners as they may damage the finish.

NOTICE& IMPORTANT SAFETY INSTRUCTIONS

* Please make sure that you have all parts indicated before you begin assembly of this item

- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * To reduce the risk of fire, electrical shock or injury to persons or property, please follow the guideline below for safe use and installation
- *The external flexible cable or cord of this lamp cannot be replaced;

If the cord is damaged, the lamp shall be destroyed


**This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. this plug will fit in a polarized outlet only one way. if the plug does not fit fully in the outlet, reverse the plug, if it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. do not attempt to disregard this safety feature.

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	UANTIT	PIECE	DESCRIPTION	PICTURE	QUANTITY
A1	Tube		3X	Ι	Tube		1X
B1	Tube		3X	J	Saddle		1X
C1	Tube	Ĵ	3X	К	Socket		1X
D	Tube		1X	L	Harp	\bigcirc	1X
Е	Fork frame	-	2X	Μ	Shade		1X
F	Tube	٩	1X	Ν	Finial	٥	1X
G	glass	¢	1X	0	Bulb		
Н	Tube	Ĵ	1X				




Model# JYL3059 Product Dimensions: 18"L X 18W X 59"H



PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product. Estimated Assembly Time: 20 minutes.

PLEASE USE ON/OFF TYPE"A" BULB MAX 100-WATT OR CFL BULB MAX 23-WATT OR LED BULB MAX 12-WATT THERE IS LED 9-WATT BULB IN THE BOX



Step 1

Make sure all parts could be aligned before assemble Do not rotate lamp body too hard avoid base screw broken Let tube(A1) go through Fork frame(E1), and screw tube(B1) onto tube(A1)

Screw Tube(D) into middle threaded part of Fork frame(E1)

Fix the Fork frame(E2) onto Tube(B1) by using Tube(C1)

Let tube(F) go through Fork frame(E2) middle hole, and screw tube(F) onto the tube(D).

Be careful not to twist the power cord and tighten securely

ENJOY YOUR LAMP

Step 2 Fix the Glass(G) onto the tube(F) Screw the tube(H) onto the Glass(G) Screw the tube(I) onto the Tube(H)

Step 3

Insert the Harp (L) into the Saddle (J). Put the shade(M) on the Harp(L), then tighten the Finial (N) into the Harp (L) Insert the bulb(O) into the socket(K).

Step 4 Put the light on a level surface to check if everything is stable.