



## Original Paper Shades by Redi Shade

### Use & Care

---

#### **Use:**

To raise, secure pleats with two included clips. To lower, remove the clips to release the pleats.

#### **Cleaning:**

Lightly dust and/or vacuum with an upholstery attachment.

#### **Caution:**

Do not immerse in water, dry clean, use ultrasonic cleaning, spot remover, or strong detergent on shade.

 Redi Shade Support: 1-888-608-6611