




Wooden Picnic Table Assembly Instruction




A-2 1pc




B 4pcs




A-1 1pc



C 2pcs




D 2pcs




E 2pcs




F 2pcs




1-1 2pcs




1-2 1pcs




2 3.5*30 16pcs




3 8*90mm 8pcs




4 8*70mm 8pcs





5 3.5*50mm 4pcs





6 6*70mm 12pcs




Align the hinge like photo
Then use screw 2 to fix it





Both Side Need Bolts





Both Side Need Bolts



Repeat Last Step to Assemble The Other Side