
Item Number: A04416

WARNING (To reduce the risk of fire, electric shock, or personal injury):

- 1. We suggest installation by a licensed electrician.
- 2. Please read the instruction carefully and save it as you may need it at a later time.
- 3. Before you start, **NEVER** attempt any work without shutting off the electricity until the work is done.
 - » Go to the main fuse, or circuit breaker, box in your home. Place the main power switch in the "**OFF**" position.
 - » Place the wall switch in the "OFF" position.
- 4. Mounting surface should be clean, dry, flat, strong enough and 1/4" larger than the canopy on all sides. Any gaps between the mounting surface and canopy exceeding 3/16" should be corrected as required.
- 5. Make sure that the ceiling or wall can stand the weight of the lamp before installation.
- 6. Make sure the voltage you are using is **120V**. The maximum wattage is **22W**.
- 7. Keep the lamp away from acidic and alkaline substances in case of damaging the surface of the lamp.
- 8. When replacing bulbs, you should turn off or unplug the lamp and you must wait until it is cool as bulbs get hot quickly.
- 9. The safety instructions appearing in this manual are not meant to cover all possible conditions that may occur. It must be understood that common sense, caution and care must be used with any electrical products.

IMAGE FOR FINISHED PRODUCT:



TOOLS REQUIRED (NOT INCLUDED):


Before starting assembly and installation please prepare the needed tools as below picture

					Contraction of the second seco
L	.adder	Phillips head.flat blade screwdriver	Electrical tape	Pliers	Wire cutter/Stripper

PARTS TYPE & QTY INCLUDING: (A) Mounting plate (1) (B) Green ground screw (1) (E) Canopy (1) (F) Knob nut (2) (G) Quick link (2) (H) Chain (I) (I) Loop (1) (J) Square frame (2) (K) Socket (4) (L) Glass shade (4) (M) Fixture body (1) (N) Quick wire connector (1)

ACCESSORIES & QTY ENCLOSED:

- (C) Wire connector (3)
- (D) Mounting screw (2)




ASSEMBLY & INSTALLATION INSTRUCTIONS:

1. Carefully remove the fixture from the carton and check that all parts and accessories are included as shown in the above illustration.

2. Make pre-installation

- Step A1 » Screw loop (I) onto the top of square frames (J). Adjust square frames (J) to the proper position.
- Step A2 » By measuring, determine the correct number of links needed for proper hanging height. Using the chain pliers, disconnect and discard the unwanted part.
- Step A3 » Attach quick links (G) to canopy (E) and loop (I) on the top of square frames (J).
- Step A4 » Carefully weave the fixture wires through chain (H) in and out of every other link and then pass wires through canopy (E). Gently pull the wires to ensure the wires are not stressed.

To make the first wire connections: Insert the black and white fixture wires into the positive terminal (marked +) and the negative terminal (marked -) of quick wire connector (N) as the illustration shown below.




3. Turn off power

Before you start the installation, NEVER attempt any work without shutting off the electricity until the work is done.


- **»** Go to the main fuse, or circuit breaker, box in your home. Place the main power switch in the "OFF" position.
- » Place the wall switch in the "OFF" position.

4. Make installation



- Step B1 » Unscrew knob nuts (F) from canopy (E) then remove mounting plate (A).
- Step B2 » Attach mounting plate (A) to the outlet box with mounting screws (D).
- Step B3 » Make the second wire connections

Connect wires as below wires connection shown. *PLEASE NOTE THAT GROUND WIRE IS BARE* COPPER WIRE, NEVER CONNECT OTHER WIRES TO GROUND WIRES.



wrap each connector with approved electrical tape. Be sure that no wire strands are exposed and then carefully tuck all wires into the outlet box.

Step B4 » Raise canopy (E) to the ceiling and secure canopy (E) in place by tightening knob nuts (F) onto the pre-assembled screws in mounting plate (A).

NOTE: canopy (E) should be snug against the ceiling with knob nuts (F). If not, remove canopy (E), adjust the threaded length of pre-assembled mounting screws on mounting plate assembly (A):

- First, unscrew the pre-assembled hex nuts.
- Then, screw the pre-assembled mounting screws in or out of mounting plate (A).
- When the secure length is achieved, tighten the pre-assembled hex nuts and back to Step B4.



4. Check everything is already installed properly, then you could turn on the light. Enjoy!

ORDERING PARTS

Keep this sheet for future reference in case you need to order replacement parts. All parts for this fixture can be ordered from the place of purchase. Be sure to use exact wording from illustration when ordering parts.

CLEANING

To clean, wipe the fixture with a soft cloth. Clean glass with a mild cleaner (such as mild and non-abrasive soap). Do not use abrasive materials such as scouring pads or powders, steel wool or abrasive paper.