



**CARE AND MAINTENANCE**

Your portable halogen work light requires very little care and maintenance. Simply clean the lens, lamp head and lamp stand regularly with a non-abrasive cleaner.

**WARNING:** Always make sure that the work light is unplugged and completely cool before attempting to clean it.

Always allow the work light to cool down completely before storing.

Store in a safe place out of the reach of children.

**ROUBLESHOOTING**

For replacement parts, call our customer service department at 1-866-994-4148, 8 a.m. - 6 p.m., EST, Monday - Thursday.

**OPERATING INSTRUCTIONS**

The work light comes on, but the lights are dimmed.

Improper voltage or power supply. The work light will only operate on standard household 120V AC/60 Hz power.

Use of an extension-cord longer than 50 ft. can reduce the voltage supplied to the light and can cause dimming or complete failure of the light. Use of an extension-cord longer than 50 ft. can cause a voltage drop that can damage the work light.

**WARNING: RISK OF SEVERE BURN** Both hands and bulbs are extremely hot during and immediately following use. Touching lamp heads or bulbs with bare hands while work lights are on can cause severe burns. Turn off and unplug work light and allow to cool completely before attempting to change bulb.

**CAUTION: RISK OF BURN** NEVER TOUCH BULB SURFACE WITH YOUR BARE HANDS. If you accidentally touch the bulb with your bare hands, wipe the bulb thoroughly with alcohol and soft cloth to remove any residue. If bulb is still hot, do not touch the bulb again until it has cooled.

**CAUTION: RISK OF DAMAGE TO WORK LIGHT** The lamp head on this work light is designed to operate safely with a single 250-watt bulb. To avoid damage to the work light, DO NOT USE A BULB OVER 250-WATTS IN THIS WORK LIGHT.

**WARRANTY**

One year limited warranty. If this product (excluding bulbs) fails due to defects in material or workmanship within one (1) year from the date of purchase, we will repair or replace the product at no cost to you.

**WARNING: RISK OF PERSONAL INJURY** To avoid being burned, always hold the work light by its foam grip handle. Never touch the bulb or the lamp head with bare hands while work lights are on.

**WARNING: RISK OF FIRE** DO NOT attempt to plug the work light into a non-grounded outlet or non-grounded power source. If the work light is connected to a power source that is not properly grounded, the power receptacle, have the proper outlet replaced by a qualified electrician. Incorrectly grounded power receptacles can cause electrical shock and death.

**DO NOT abuse the power supply cord.** Never carry the work light by the power supply cord or pull the cord to disconnect the plug from the outlet receptacle. Keep cord away from heat, oil, and sharp edges.

**Adjusting the light direction:** Adjust the light direction by loosening the twist knob on the side of the lamp head. Using the handle, adjust the lamp head to desired position and tighten knob.

**Risk of personal injury:** To avoid being burned, always hold the work light by its foam grip handle. Never touch the bulb or the lamp head with bare hands while work lights are on.

**WARNING: RISK OF FIRE** DO NOT attempt to plug the work light into a non-grounded outlet or non-grounded power source. If the work light is connected to a power source that is not properly grounded, the power receptacle, have the proper outlet replaced by a qualified electrician. Incorrectly grounded power receptacles can cause electrical shock and death.

**ONE YEAR LIMITED WARRANTY**

If this product (excluding bulbs) fails due to defects in material or workmanship within one (1) year from the date of purchase, we will repair or replace the product at no cost to you.

**WARNING: RISK OF PERSONAL INJURY** To avoid being burned, always hold the work light by its foam grip handle. Never touch the bulb or the lamp head with bare hands while work lights are on.

**WARNING: RISK OF FIRE** DO NOT attempt to plug the work light into a non-grounded outlet or non-grounded power source. If the work light is connected to a power source that is not properly grounded, the power receptacle, have the proper outlet replaced by a qualified electrician. Incorrectly grounded power receptacles can cause electrical shock and death.

**DO NOT abuse the power supply cord.** Never carry the work light by the power supply cord or pull the cord to disconnect the plug from the outlet receptacle. Keep cord away from heat, oil, and sharp edges.

**Adjusting the light direction:** Adjust the light direction by loosening the twist knob on the side of the lamp head. Using the handle, adjust the lamp head to desired position and tighten knob.

**Risk of personal injury:** To avoid being burned, always hold the work light by its foam grip handle. Never touch the bulb or the lamp head with bare hands while work lights are on.

**WARNING: RISK OF FIRE** DO NOT attempt to plug the work light into a non-grounded outlet or non-grounded power source. If the work light is connected to a power source that is not properly grounded, the power receptacle, have the proper outlet replaced by a qualified electrician. Incorrectly grounded power receptacles can cause electrical shock and death.

**ONE YEAR LIMITED WARRANTY**

If this product (excluding bulbs) fails due to defects in material or workmanship within one (1) year from the date of purchase, we will repair or replace the product at no cost to you.

**WARNING: RISK OF PERSONAL INJURY** To avoid being burned, always hold the work light by its foam grip handle. Never touch the bulb or the lamp head with bare hands while work lights are on.

**WARNING: RISK OF FIRE** DO NOT attempt to plug the work light into a non-grounded outlet or non-grounded power source. If the work light is connected to a power source that is not properly grounded, the power receptacle, have the proper outlet replaced by a qualified electrician. Incorrectly grounded power receptacles can cause electrical shock and death.

**DO NOT abuse the power supply cord.** Never carry the work light by the power supply cord or pull the cord to disconnect the plug from the outlet receptacle. Keep cord away from heat, oil, and sharp edges.

**Adjusting the light direction:** Adjust the light direction by loosening the twist knob on the side of the lamp head. Using the handle, adjust the lamp head to desired position and tighten knob.

**Risk of personal injury:** To avoid being burned, always hold the work light by its foam grip handle. Never touch the bulb or the lamp head with bare hands while work lights are on.

**WARNING: RISK OF FIRE** DO NOT attempt to plug the work light into a non-grounded outlet or non-grounded power source. If the work light is connected to a power source that is not properly grounded, the power receptacle, have the proper outlet replaced by a qualified electrician. Incorrectly grounded power receptacles can cause electrical shock and death.

**ONE YEAR LIMITED WARRANTY**

If this product (excluding bulbs) fails due to defects in material or workmanship within one (1) year from the date of purchase, we will repair or replace the product at no cost to you.

**WARNING: RISK OF PERSONAL INJURY** To avoid being burned, always hold the work light by its foam grip handle. Never touch the bulb or the lamp head with bare hands while work lights are on.

**WARNING: RISK OF FIRE** DO NOT attempt to plug the work light into a non-grounded outlet or non-grounded power source. If the work light is connected to a power source that is not properly grounded, the power receptacle, have the proper outlet replaced by a qualified electrician. Incorrectly grounded power receptacles can cause electrical shock and death.

**DO NOT abuse the power supply cord.** Never carry the work light by the power supply cord or pull the cord to disconnect the plug from the outlet receptacle. Keep cord away from heat, oil, and sharp edges.

**Adjusting the light direction:** Adjust the light direction by loosening the twist knob on the side of the lamp head. Using the handle, adjust the lamp head to desired position and tighten knob.

**Risk of personal injury:** To avoid being burned, always hold the work light by its foam grip handle. Never touch the bulb or the lamp head with bare hands while work lights are on.

**WARNING: RISK OF FIRE** DO NOT attempt to plug the work light into a non-grounded outlet or non-grounded power source. If the work light is connected to a power source that is not properly grounded, the power receptacle, have the proper outlet replaced by a qualified electrician. Incorrectly grounded power receptacles can cause electrical shock and death.

**ONE YEAR LIMITED WARRANTY**

If this product (excluding bulbs) fails due to defects in material or workmanship within one (1) year from the date of purchase, we will repair or replace the product at no cost to you.

**WARNING: RISK OF PERSONAL INJURY** To avoid being burned, always hold the work light by its foam grip handle. Never touch the bulb or the lamp head with bare hands while work lights are on.

**WARNING: RISK OF FIRE** DO NOT attempt to plug the work light into a non-grounded outlet or non-grounded power source. If the work light is connected to a power source that is not properly grounded, the power receptacle, have the proper outlet replaced by a qualified electrician. Incorrectly grounded power receptacles can cause electrical shock and death.

**DO NOT abuse the power supply cord.** Never carry the work light by the power supply cord or pull the cord to disconnect the plug from the outlet receptacle. Keep cord away from heat, oil, and sharp edges.

**Adjusting the light direction:** Adjust the light direction by loosening the twist knob on the side of the lamp head. Using the handle, adjust the lamp head to desired position and tighten knob.

**Risk of personal injury:** To avoid being burned, always hold the work light by its foam grip handle. Never touch the bulb or the lamp head with bare hands while work lights are on.

**WARNING: RISK OF FIRE** DO NOT attempt to plug the work light into a non-grounded outlet or non-grounded power source. If the work light is connected to a power source that is not properly grounded, the power receptacle, have the proper outlet replaced by a qualified electrician. Incorrectly grounded power receptacles can cause electrical shock and death.

**ONE YEAR LIMITED WARRANTY**

If this product (excluding bulbs) fails due to defects in material or workmanship within one (1) year from the date of purchase, we will repair or replace the product at no cost to you.

**WARNING: RISK OF PERSONAL INJURY** To avoid being burned, always hold the work light by its foam grip handle. Never touch the bulb or the lamp head with bare hands while work lights are on.

**WARNING: RISK OF FIRE** DO NOT attempt to plug the work light into a non-grounded outlet or non-grounded power source. If the work light is connected to a power source that is not properly grounded, the power receptacle, have the proper outlet replaced by a qualified electrician. Incorrectly grounded power receptacles can cause electrical shock and death.

**DO NOT abuse the power supply cord.** Never carry the work light by the power supply cord or pull the cord to disconnect the plug from the outlet receptacle. Keep cord away from heat, oil, and sharp edges.

**Adjusting the light direction:** Adjust the light direction by loosening the twist knob on the side of the lamp head. Using the handle, adjust the lamp head to desired position and tighten knob.

**Risk of personal injury:** To avoid being burned, always hold the work light by its foam grip handle. Never touch the bulb or the lamp head with bare hands while work lights are on.

**WARNING: RISK OF FIRE** DO NOT attempt to plug the work light into a non-grounded outlet or non-grounded power source. If the work light is connected to a power source that is not properly grounded, the power receptacle, have the proper outlet replaced by a qualified electrician. Incorrectly grounded power receptacles can cause electrical shock and death.

**ONE YEAR LIMITED WARRANTY**

If this product (excluding bulbs) fails due to defects in material or workmanship within one (1) year from the date of purchase, we will repair or replace the product at no cost to you.

**WARNING: RISK OF PERSONAL INJURY** To avoid being burned, always hold the work light by its foam grip handle. Never touch the bulb or the lamp head with bare hands while work lights are on.

**WARNING: RISK OF FIRE** DO NOT attempt to plug the work light into a non-grounded outlet or non-grounded power source. If the work light is connected to a power source that is not properly grounded, the power receptacle, have the proper outlet replaced by a qualified electrician. Incorrectly grounded power receptacles can cause electrical shock and death.

**DO NOT abuse the power supply cord.** Never carry the work light by the power supply cord or pull the cord to disconnect the plug from the outlet receptacle. Keep cord away from heat, oil, and sharp edges.

**Adjusting the light direction:** Adjust the light direction by loosening the twist knob on the side of the lamp head. Using the handle, adjust the lamp head to desired position and tighten knob.

**Risk of personal injury:** To avoid being burned, always hold the work light by its foam grip handle. Never touch the bulb or the lamp head with bare hands while work lights are on.

**WARNING: RISK OF FIRE** DO NOT attempt to plug the work light into a non-grounded outlet or non-grounded power source. If the work light is connected to a power source that is not properly grounded, the power receptacle, have the proper outlet replaced by a qualified electrician. Incorrectly grounded power receptacles can cause electrical shock and death.

**ONE YEAR LIMITED WARRANTY**

If this product (excluding bulbs) fails due to defects in material or workmanship within one (1) year from the date of purchase, we will repair or replace the product at no cost to you.

**WARNING: RISK OF PERSONAL INJURY** To avoid being burned, always hold the work light by its foam grip handle. Never touch the bulb or the lamp head with bare hands while work lights are on.

**WARNING: RISK OF FIRE** DO NOT attempt to plug the work light into a non-grounded outlet or non-grounded power source. If the work light is connected to a power source that is not properly grounded, the power receptacle, have the proper outlet replaced by a qualified electrician. Incorrectly grounded power receptacles can cause electrical shock and death.

**DO NOT abuse the power supply cord.** Never carry the work light by the power supply cord or pull the cord to disconnect the plug from the outlet receptacle. Keep cord away from heat, oil, and sharp edges.

**Adjusting the light direction:** Adjust the light direction by loosening the twist knob on the side of the lamp head. Using the handle, adjust the lamp head to desired position and tighten knob.

**Risk of personal injury:** To avoid being burned, always hold the work light by its foam grip handle. Never touch the bulb or the lamp head with bare hands while work lights are on.

**WARNING: RISK OF FIRE** DO NOT attempt to plug the work light into a non-grounded outlet or non-grounded power source. If the work light is connected to a power source that is not properly grounded, the power receptacle, have the proper outlet replaced by a qualified electrician. Incorrectly grounded power receptacles can cause electrical shock and death.