
Assembly Instruction

Item: N715P170418 - DINING CHAIR



If you have any questions, please feel free to contact us. Email: lowes.team@qualfurn.net


Page 1/8

Please read these instructions fully before starting assembly:

- 1. Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.
- 2. Kindly follow the assembly instructions step by step.
- 3. Do not tighten all screws and bolts until the table is fully assembled.
- 4. Unscrew the protective plastique supports from the metal insert of the table legs before assembly.
- 5. Parts of the assembly will be easier with 2 people.

Care and maintenance:

Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.



Part list for one	Hardware list for one
A	
	1/4"x 35mm
Seat Cushion (1Pc)	BOLT (1Pc)
B	
	1/4"x 50mm
Chair Back (1Pc)	BOLT (4Pcs)
	1/4"x 70mm
Front Leg (Left) (1Pc)	BOLT (4Pcs)
	4
	Ø1/4"x13x1.5mm
Front Leg (Right) (1Pc)	FLAT WASHER (9Pcs)
E	5
do	Ø1/4"x16x1.5mm
Front Stretcher (1Pc)	LOCK WASHER (9Pcs)
F ·	6
0:1 01 11 (07)	4 All 14 (4D)
Side Stretcher (2Pcs)	4mm Allen Wrench (1Pc)
Note: Tool required (not provided)	(7) Anna
Screwdriver	#8 x 1-1/2"
	Wood Screw (6Pcs)
	Page 4/8

