
4-Piece Acapulco Chair Sets

Assembly Instructions

A102-003-001



KINDLY NOTICE- Please read these instructions carefully before starting assembly

HASSEL-FREE WARRANTY

We proudly provid 1-YEAR warranty, if there is any questions with the products, please feel free to contact with us.

Email: support@patio-outdoor.com



The assembly will be easier with 2 people while 1 person could also do the job.





Around 30 MINS ASSEMBLY

Parts List

Note: All parts of the screws should not be completely tightened the first time please tighten all screws after all parts are installed.

Parts required





J	Prawe / Right	1
K		1
L		1
М	Tu dom	1
N	1 ton	1
0	<u>"</u> "	1
Р		1
Q		1


R	M6x16mm	16
S	M6x28mm	1
Т	M 6x35mm	6
U	0)	1
V	Φ13xΦ6.5x1.0mm	26
		1

Assembly-Single Chair

Note: All parts of the screws should not be completely tightened the first time please tighten all screws after all parts are installed.


Step1

Use E to connect C and D by inserting it into the interface between C and D.




Step3

Align the orifices of C and D and insert backrest B slowly.




Step2

As picture, please assemble A on top of C and D.



Step4

Turn the parts assembled in step 3 upside down, the holes for C/D connection A are fixed using T and V, the holes for C/D connection E are fixed using R and V.



Please repeat the assembly of another chair according to the previous steps

Assembly-Loveseat

Note: All parts of the screws should not be completely tightened the first time please tighten all screws after all parts are installed.

Step1

Use K to connect J and H by inserting it into the interface between C and D.


Note: Ensuring proper alignment of holes.


Step2


As picture, please assemble F on top of J and H.

Step3

Align the orifices of J and H and insert backrest G slowly.









Step4

Turn the parts assembled in step 3 upside down, the holes for H/J connection F are fixed using T and V, the holes for H/J connection K are fixed using R and V. Place Q between the holes in K and F, use U and V to fix K, Q and F.

Step5

Place P on top of the holes in G and F, then use R and V to fix the part.






Assembly-Table

Note: All parts of the screws should not be completely tightened the first time please tighten all screws after all parts are installed.

Step1

Put L on the ground. M and N are inserted crosswise into the holes of L, use R and V to fix the holes above the L.

Note: The N is placed above M




Step3

Turn the parts assembled in step 2 upside down, place O above L.


Step2


Fixing the connection holes of M and N with S and V.



Step4

As picture, the table is assembled.







For a period of one (1) years after date of purchase, the Manufacturer will either repair or replace defective components in accordance with this Limited Warranty. This warranty is between the Manufacturer and the original purchaser and is valid only when accompanied by the original purchaser's sales receipt showing original date of purchase

The manufacturer or its authorized dealer can accept or reject warranty claims based on its findings. This warranty applies in normal residential use only and is not intended for commercial use. The Manufacturer can make substitutions as required of materials, components, and sub-components of comparable value and utility. This warranty is limited to product repair or replacement (to be determined solely by the Manufacturer). Warranty return is limited to only the single affected component.

This limited warranty covers only manufacturing defects and does not cover normal wear and tear, damage due to acts of nature (such as, but not limited to freezing or high winds), abuse or misuse, including chemical damage from suntan oil or other chemicals, exposure to extreme heat or cold, abrasion or excessive weight. This product is intended to be used in standard installations only. This warranty is voidif the product is not used for its intended purpose. The Manufacturer disclaims liability for any aspect of installation and any inconvenience caused by a defective part of a component

Certain items are not covered by this warranty. These include, but are not limited to the following:

- 1. Components subjected to abuse, including abuse intended to simulate failure
- 2. Damages caused by retailer, shipper or installation error (such as scratches, dents, tears, chips, etc.)
- 3. Any part that only shows normal wear and tear on the surface, including debris, scratches, or material stretching and stitching.
- **4.** Tears, punctures, scratches or any damage caused by improper installation or use.

General care & maintenance

Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

* If you need after-sales service, please provide the original purchase record and a brief description of the problem. Please also provide your email address or mobile number