







Attention please :








**Improper use of screws may cause the product surface damage!
Please be careful when installing.**

**To prevent you from confusing the accessories and boards, Please
do not mix the parts of different units when you buy two or more
products at the same time.**

READ AND SAVE THIS INSTRUCTIONS FOR FUTURE USE

ASSEMBLY & INSTRUCTION MANUAL






A x101 	B x101 	C x16 	D x 8 	E x10 	F x 4 BLACK 	G x 5 
H x10 	I x48 	J x 8 	K x 4 	L x 8 	M x 2 	N x 8 
O x 2 	P x 4 	Q x 2 	R x 2 	S x16 	T x 1 	
U x16 						

3x14mm

1


G x 5



2

M x 2

A x 5





F x 4


B x 5



BLACK




3




E x 4

T x 1





4



T x 1

A x 16




E x 6




5

B x 8




6




7



B x 8



8




9



x2


A x 8




B x 8



10




A x10




B x10



11




12




13

B x 4




14


B x 4




15




16



17



18



B x 4








Diagram illustrating the installation of the upper cabinet door (25) onto the upper cabinet frame (23) using the upper cabinet hinge (26).




22



x2



23



x2

24

A x12




25


B x 6



D x 4



26




B x 6



D x 4




27




I x 8



J x 4







K x 2



L x 4



28



29

