
Item Number: A04074-A04622

WARNING (To reduce the risk of fire, electric shock, or injury to persons):


- 1. We suggest installation by a licensed electrician.
- 2. Please read the instruction carefully and save it as you may need it at later time.
- 3. Before you start, NEVER attempt any work without shutting off the electricity until the work is done.A) Go to the main fuse, or circuit breaker, box in your home. Place the main power switch in the "OFF" position.B) Place the wall switch in the "OFF" position.
- 4. Mounting surface should be clean, dry, flat, strong enough and 1/4" larger than the canopy on all side. Any gaps between the mounting surface and canopy exceeding 3/16" should be corrected as required.
- 5. Make sure that the ceiling or wall can stand the weight of the lamp before installation.
- 6. Make sure the voltage you are using is **120V**. The maximum wattage is **Type B,Max 40W** per bulb.
- 7. Keep the lamp away from acidic and alkaline substances in case of damaging the surface of the lamp.
- 8. When replacing bulb, you should turn off or unplug the lamp and you must wait until it is cool as bulbs get hot quickly.
- 9. The safety instructions appearing in this manual are not meant to cover all possible conditions that may occur. It must be understood that common sense, caution and care must be used with any electrical products.

IMAGE FOR FINISHED PRODUCT:



TOOLS REQUIRED (NOT INCLUDED):


Before doing assembly and installation please prepare the needed tools as below picture





PARTS INCLUDING:

- (C) Green ground screw (1)
- (D) Mounting plate (1)
- (E) Back plate (1)
- (F) Knob nut (2)
- (G) Socket (1)
- (H) Glass shade (1)



ASSEMBLY & INSTALLATION INSTRUCTIONS:


- 1. Carefully remove the fixture from the carton and check that all parts and accessories are included as shown in the above illustration.
- 2. Turn off power

(A) Mounting screw (2)

(B) Plastic wire connector (3)

Before you start the installation, NEVER attempt any work without shutting off the electricity until the work is done.

- A. Go to the main fuse, or circuit breaker, box in your home. Place the main power switch in the "OFF" position.
- B. Place the wall switch in the "OFF" position.
- 3. Make assembly



Page: -2-/3



Step A1: Unscrew knob nuts (F) from mounting plate (D), then set aside for the following steps.

Step A2: Secure mounting plate (D) to outlet box with mounting screws (A).

Step A3: Make wire connections

Connect wires as below wires connection shown. PLEASE NOTE THAT GROUND WIRE IS BARE COPPER WIRE, NEVER CONNECT OTHER WIRES TO GROUND WIRES.

Connect ground wires according to the below chart

Connect wires according to the below chart

Α	В	Connect Black or Red Supply Wire to:	Connect White Supply Wire to:
OUTLET BOX	OUTLET BOX	Black	White
GROUND FIXTURE GROUND	GROUND FIXTURE GROUND CUPPED WASHER	*Parallel cord (round & smooth)	*Parallel cord (square & ridged)
		Clear,Brown,Gold or Black without tracer	Clear,Brown,Gold or Black with tracer
		Insulated wire (other than green) with copper conductor	Insulated wire (other than green) with silver conductor
DIMPLES		*Note: When parallel wires (SPT I & SPT II) are used. The neutral wire is square shaped	
GREEN GROUND SCREW	GREEN GROUND SCREW	or ridged and the other wire will be shape or smooth (see illus.)	round in Neutral Wire
OOKEW	CONLETT	22,2 2. 222 (666 masi)	Neutral Wife

Twist wires together with plastic wire connector until tightly joined, and wrap each connector with approved electrical tape. Be sure that no wire strands are exposed and then carefully tuck all wires into the outlet box.

Step A4: Align the holes in the back plate (E) with the pre-assembled mounting screws, then attach the back plate (E) using the previously removed knob nuts (F). Hand tighten until snug.

Step A5: Install bulbs (Not included) (Please do not exceed the maximum wattage recommended on the socket.) Screw the glass shade (H) onto the socket (G).

Check everything is installed properly, then you could turn on the light. Enjoy!

CLEANING

To clean, wipe the fixture with a soft cloth. Clean glass with a mild cleaner (such as mild and non-abrasive soap). Do not use abrasive materials such as scouring pads or powders, steel wool or abrasive paper.

ORDERING PARTS

Keep this sheet for future reference in case you need to order replacement parts. All parts for this fixture can be ordered from the place of purchase. Be sure to use exact wording from illustration when ordering parts.