




PARTS LIST / LISTE DES PIE CES / LISTA DE PIEZAS

ITEM NO. / ARTICLE NO. / ARTICULO NO : DS-D438-300-1/ 2

DESCRIPTION / DESCRIPCION : Bookcase / Bibliothèque / Biblioteca



* Replaceable Part




ASSEMBLY INSTRUCTIONS / NOTICE DE MONTAGE / INSTRUCCIONES DE MONTAJE


ITEM NO. / ARTICLE NO. / ARTICULO NO : DS-D438-300-1/ 2

DESCRIPTION / DESCRIPCIÓN : Bookcase / Bibliothèque / Biblioteca


STEP 1 / ETAPA 1 / ÉTAPE 1




STEP 2 / ETAPA 2 / ÉTAPE 2




STEP 3 / ETAPA 3 / ÉTAPE 3



STEP 4 / ETAPA 4 / ÉTAPE 4



COMPLETED / TERMINÉ / TERMINADA



Turn the bookcase upright and place on level surface.
Adjust the adjustable feet so that bookcase is level and does not wobble.

Tournez la bibliothèque à la verticale et placez-la sur une surface plane.
Ajustez les pieds réglables de sorte que la bibliothèque soit de niveau et ne vacille pas.



Coloque la estantería en posición vertical y colóquela en una superficie nivelada.
Ajuste los pies ajustables para que la estantería esté nivelada y no se tambalee.



REPLACEABLE PART / PARTIE REMPLACABLE / PARTE REEMPLAZABLE


ITEM NO. / ARTICLE NO. / ARTICULO NO : DS-D438-300-1/ 2

DESCRIPTION / DESCRIPCIÓN : Bookcase / Bibliothèque / Biblioteca




A *

x1 RD438-300-1/ 2-SHEIFA - Shelf A
étagère A
repisa A




B *

x1 RD438-300-1/ 2-SHEIFB - Shelf B
étagère B
repisa B




C *

x1 RD438-300-1/ 2-SHEIFC - Shelf C
étagère C
repisa C



D *

x1 RD438-300-1/ 2-SHEIFD - Shelf D
étagère D
repisa D



*

x1 RD438-300-HWKIT - Hardware kit list
Liste des pièces de quincaillerie
Lista del kit de materiales