



## REPLACEMENT KIT

Kit Model	Kit Description	Part No.
	Replacement O-ring kit	10,12,15,16,18,21.1,22,25,40.1,40.4,40.5,40.7,40.8,40.11,44
	Replacement trigger kit	40
	Replacement drive blade and bumper kit	14,21
	Replacement spring	56

## KIT DE REEMPLAZODE

Kit Modelo	Kit Descripción	Número De Pieza
	Kit de reemplazode Junta tórica	10,12,15,16,18,21.1,22,25,40.1,40.4,40.5,40.7,40.8,40.11,44
	Kit de reemplazo de gatillo	40
	Kit de reemplazo de álabe del impulsor y protector	14,21
	Reemplazo de primavera	56