



WF285324
N717P220218


















Detail View Vue détaillée





WF285324



N717P220218

1		2		3	
Wood board-1pc		Support of Wood board-2pcs		Floor-1pc	
4		5		6	
Upper slat of front panel-1pc		Lower slat of front panel-1pc		Right door-1pc	
7		8		9	
Left door-1pc		Upper of back panel-1pc		Top-1pc	
10		11		12	
Right side panel-1pc		Left side panel-1pc		Lower of back panel-1pc	
13		14		15	
Back part of Top part-1pc		Left part of Top part-1pc		Right part of Top part-1pc	


Hardware List
Liste du matériel


A	 3.5*40 Ph zinc screws-22+1pcs	B	 M4*32 Ph zinc bolt-2+1pcs	C	 3.0*30 Ph zinc screws-4+1pcs	D	 3.0*35 Ph zinc screws-20+1pcs
E	 3.0*18 Black screws-6+1pcs	F	 Black Hook-1pc	G	 Door Knob-2pcs	H	 Angle steel-2pcs
I	 Ground nail-2pcs						

ASSEMBLY TOOLS REQUIRED(NOTINCLUDED)
Outils d'assemblage requis (non inclus)




PLEASE BE CAREFUL DO NOT DAMAGE THE HOLE POSITION WHEN
YOU USE POWERTOOLS!
Veuillez faire attention à ne pas endommager la position du
trou lors de l'utilisation d'outils électriques!







3.




4.




5.




6.




7.



8.



9.



10.

