


Reclining Lounge Chair

Assembly Instructions

A042-001-001



KINDLY NOTICE- Please read these instructions carefully before starting assembly

HASSEL-FREE WARRANTY

We proudly provide 1-YEAR warranty, if there are any questions with the products, please feel free to contact with us.

✉ Email: support@patio-outdoor.com



The assembly will be easier with 2 people while 1 person could also do the job.























Around 30 MINS ASSEMBLY

Parts List

Note: All parts of the screws should not be completely tightened the first time
please tighten all screws after all parts are installed.

Overview




				
A 1PCS	B 1PCS	C 1PCS	D 1PCS	E 1PCS
				
F 1PCS	G 11PCS	H 1PCS	I 1PCS	J 2PCS
				
M8X40mm K 4PCS	M6X35mm L 8PCS	M6X15mm M 16PCS	N 8PCS	T 1PCS
				
Q 4PCS	R 28PCS	S 4PCS	U 1PCS	


Assembly

Note: All parts of the screws should not be completely tightened the first time
please tighten all screws after all parts are installed.


1




①D1pc



①H1pc



①I1pc




④L4pcs



④N4pcs



⑧R8pcs



By connecting L and R to R and N, H and I can be stably installed on D.

Assembly

Note: All parts of the screws should not be completely tightened the first time please tighten all screws after all parts are installed.

2



ⓔ 1pc




ⓕ 1pc



Ⓜ 8pcs



Ⓡ 8pcs




Insert M into R to fix E and F.

Note: When installing part E, side “a” should be installed next to part F.


Assembly

Note: All parts of the screws should not be completely tightened the first time please tighten all screws after all parts are installed.


3



Ⓔ 1pc



Ⓙ 2pcs



Ⓛ 4pcs




Ⓝ 4pcs



Ⓞ 4pcs



Ⓡ 8pcs




Use Ox4pcs to connect the J and the left and right sides. Insert L into R to connect with N and R on the other side to fix G.


Assembly

Note: All parts of the screws should not be completely tightened the first time please tighten all screws after all parts are installed.


4




Ⓐ 1pc



Ⓑ 1pc




Ⓚ 4pcs




Ⓚ 4pcs



Ⓢ 4pcs





Fix A and B on either side of G by using KSQ.



Assembly



Note: All parts of the screws should not be completely tightened the first time please tighten all screws after all parts are installed.



Note: When connecting backrest C to seat D, slide backrest C downward until it's slot fully snapped into seat D.

Assembly



Note: All parts of the screws should not be completely tightened the first time please tighten all screws after all parts are installed.



Note: When connecting backrest C to seat D, slide backrest C downward until it's slot fully snapped into seat D.

Assembly

Note: All parts of the screws should not be completely tightened the first time please tighten all screws after all parts are installed.




Place U on the installed CDEF.


Assembly

Note: All parts of the screws should not be completely tightened the first time please tighten all screws after all parts are installed.

8



When sitting on the recliner and lying back, the back will recline while the footrest rises.



When leveraging armrests to change from lying to reclining position, the back will rise and the footrest falls.



WARRANTY

Outdoor furniture
1-year Warranty Program

For a period of one (1) years after date of purchase, the Manufacturer will either repair or replace defective components in accordance with this Limited Warranty. This warranty is between the Manufacturer and the original purchaser and is valid only when accompanied by the original purchaser's sales receipt showing original date of purchase

The manufacturer or its authorized dealer can accept or reject warranty claims based on its findings. This warranty applies in normal residential use only and is not intended for commercial use. The Manufacturer can make substitutions as required of materials, components, and sub-components of comparable value and utility. This warranty is limited to product repair or replacement (to be determined solely by the Manufacturer). Warranty return is limited to only the single affected component.

This limited warranty covers only manufacturing defects and does not cover normal wear and tear, damage due to acts of nature (such as, but not limited to freezing or high winds), abuse or misuse, including chemical damage from suntan oil or other chemicals, exposure to extreme heat or cold, abrasion or excessive weight. This product is intended to be used in standard installations only. This warranty is void if the product is not used for its intended purpose. The Manufacturer disclaims liability for any aspect of installation and any inconvenience caused by a defective part of a component

Certain items are not covered by this warranty. These include, but are not limited to the following:

1. Components subjected to abuse, including abuse intended to simulate failure
2. Damages caused by retailer, shipper or installation error (such as scratches, dents, tears, chips, etc.)
3. Any part that only shows normal wear and tear on the surface, including debris, scratches, or material stretching and stitching.
4. Tears, punctures, scratches or any damage caused by improper installation or use.

General care & maintenance

Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

**** If you need after-sales service, please provide the original purchase record and a brief description of the problem. Please also provide your email address or mobile number***