

MMA TARGET BAG INFLATABLE PUNCHING BAG MODEL# 8911TB

PRODUCT MANUAL - VERSION 3.21.01





CUSTOMER SERVICE



GQBrands.com • CustomerService@GQBrands.com • 1-866-498-5269 • 4401 Samuell Blvd, Ste 150, Mesquite, TX 75149

CUSTOMER SERVICE INFORMATION

Thank you for purchasing: MMA TARGET BAG

MODEL# 8911TB

If you have an issue with your item, do not return. Please report items that are damaged or missing parts to the manufacturer GQ Brands within three days of delivery. Contact customer service at customerservice@gqbrands.com to open a ticket.

At GQ Brands[®], we want all of our customers to be completely satisfied with their purchase. Take time to review the contents of the product you have just received to make sure that all of the parts are included. If you find that any parts are missing or damaged, we will provide replacement parts at no charge within 30 days of purchase. **Please Note:** In the interest of better quality and value, we are constantly improving and updating our product information. Most up to date manuals, warnings and product information can be found at: https://www.globalqualitybrands.com/warnings

To register you product please visit: www.globalqualitybrands.com/product-registration or Scan code:



To order these parts, or if you have any other questions or concerns about this GQ Brands product, please contact us at PureFun.net

GQ Brands® Phone: 866-498-5269 Email: CustomerService@GQBrands.com 4401 Samuell Blvd, Ste 150, Mesquite, TX 75149

Please be sure to include the following information when you contact Customer Service:

YOUR NAME:	RETAILER WHERE PURCHASED:
YOUR MAILING ADDRESS:	DATE OF PURCHASE:
YOUR EMAIL ADDRESS:	ORDER NUMBER: (If Available)
PRODUCT NAME:	PO NUMBER ON BOX: (If Available)
PRODUCT MODEL#:	QUANTITY NEEDED:
PART NUMBER	SERIAL NUMBER:

LIMITED WARRANTY

Global Quality Brands® warrants this product to be free from defects in workmanship and materials under normal use and conditions for a period of **90 DAYS FROM THE DATE OF ORIGINAL PURCHASE.** This Limited Warranty is not transferable and is available only for the original purchaser of the Product. The Company's obligation under this warranty is limited to replacing or repairing the Product, at the discretion of the company.

All warranty coverage extends only to the original retail purchaser from the date of purchase, GQBrands obligation under this warranty is limited to replacing or repairing, at Global Quality Brands® option. All products for which a warranty claim is made must be received by Global Quality Brands® and accompanied by sufficient proof of purchase (photocopy of the original store receipt, indicating the date of purchase). All freight and handling fees are the responsibility of the consumer to pay, both to and from Global Quality Brands®. All warranty claims must be pre-authorized by Global Quality Brands®. All warranty claims must be pre-authorized by Global Quality Brands® pre-authorization can be obtained by calling 866-498-5269.

This warranty does not cover ordinary wear and tear, weathering, failure to follow directions, improper installation, improper maintenance, or acts of nature, (such as damage caused by wind, lightning, snow, water, or ice) weather damage, damage caused by unauthorized repair work or damage caused by improper use of the products are not covered by the product warranty. No other warranty beyond that specifically set forth above is authorized by GQ Brands[®].

GLOBAL QUALITY BRANDS® IS NOT RESPONSIBLE OR LIABLE FOR INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE PRODUCT OR OTHER DAMAGES WITH RESPECT TO ANY ECONOMIC LOSS, LOSS OF PROPERTY, LOSS OF REVENUE OR PROFITS, LOSS OF ENJOYMENT OR USE, COST OF REMOVAL, INSTALLATION OR OTHER CONSEQUENTIAL DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. ACCORDINGLY, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

THE WARRANTY EXTENDED HEREUNDER IS IN LIEU OF ALL OTHER WARRANTIES AND GLOBAL QUALITY BRANDS®, SPECIFICALLY DISCLAIMS ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE IS LIMITED IN ITS SCOPE AND DURATION TO THE TERMS SET FORTH HEREIN. SOME STATES DO NOT ALLOW LIMITATION ON HOW LONG AN IMPLIED WARRANTY LASTS. ACCORDINGLY, THE ABOVE LIMITATION MAY NO APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE.

WHILE EVERY ATTEMPT IS MADE TO ENSURE THE HIGHEST DEGREE OF PROTECTION IN ALL EQUIPMENT, WE CANNOT GUARANTEE FREEDOM OF INJURY. THE USER ASSUMES ALL RISK OF INJURY DUE TO USE OR INSTALLATION. ALL MERCHANDISE IS SOLD ON THIS CONDITION, WHICH NO REPRESENTATIVE OF GQ BRANDS® CAN WAIVE OR CHANGE.

1-866-498-5269



IMPORTANT MESSAGE

Please read all of the warnings and directions below prior to assembly. This trampoline comes equipped with warnings and instructions for the assembly, care, maintenance and use of the trampoline. This information must be read by all trampoline supervisors and users before any person is allowed to jump on the trampoline.

ADULT ASSEMBLY REQUIRED

CHOKING HAZARD - Small Parts **NOT** for children under 3 years of age.

WARNING:

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risks of injury due to use and installation. All merchandise is sold on this condition, which no representative of the company can waive or change.

PROPOSITION 65

THIS PRODUCT CAN POSSIBLY EXPOSE YOU TO CHEMICALS INCLUDING DI(2-ETHYLHEXYL) PHTHALATE (DEHP). WHICH IS KNOWN TO THE STATE OF CALIFORNIA TO CAUSE CANCER AND BIRTH DEFECTS OR OTHER REPRODUCTIVE HARM. FOR MORE INFORMATION GO TO WWW.P65WARNINGS.CA.GOV.

Please read these warnings and the information in this manual in its entirety.

Failure to comply with the following instructions may increase the risk of serious injury and/or death:

- The owner and supervisors of this product are responsible to make sure all users are aware of the warnings and use specified in this manual.
- Ensure the punching bag has been assembled correctly, per the instructions in the manual.
- This product is recommended for use by children and adults ages 6 and up.
- The contents are not suitable for children under 3 years. This product contains small parts, which may cause choking.
- Use this product only with mature, knowledgeable supervision.
- The product bounces back when in use. To avoid injury keep at a safe distance during play.
- DO NOT over-inflate bag
- DO NOT use the bag if it will not fully inflate.
- DO NOT store punching bag outdoors or where exposed to moisture or extreme temperatures.
- DO NOT allow other persons or children to stand or sit near the bag while in use.
- DO NOT drag this product on the ground when moving.
- DO NOT use this product as a flotation device or pool toy
- This punching bag is only designed for normal residential use. It is NOT intended for commercial applications and/or in public areas such as schools, parks, day cares, commercial/communal gyms, etc. and will void warranty if used in this fashion.

- ALWAYS ensure base is filled with appropriate amount of water
- before use.
- ALWAYS remove jewelry, belt buckles or any other sharp objects before using this bag.
- ALWAYS secure the bag against unauthorized and unsupervised use.
- Indoor use position so that there is 8 feet of distance between the bag and foreign objects.
- Outdoor use position well away from water on flat firm ground; ideally grass.
- Ensure area around punching bag is clear of any toys/ obstacles that may cause injury.
- Keep bag away from hot surfaces or open flames while in use or stored away.
- Keep bag away from sharp or pointy objects and pets.
- Dispose of all packaging materials safely and per local ordinance
- Please read and refer to other warnings and use information in the instructions before use.
- Retain this manual for future reference

Δ

ASSEMBLY INSTRUCTIONS

To assemble the bag properly, you must follow all instruction steps below. Do not attempt to alter any components or parts or skip any steps below.

INSTRUCTIONS:

- 1. Open the valve on the bottom base of the bag and fill with water.
- 2. Securely close the valve.
- 3. Locate the air valve on the side of the bag and open.
- 4. Inflate the bag with standard Foot Pump included.
- 5. Fill until bag is upright and most of the wrinkles have straightened out.
- 6. Close air valve and push gently into the body.

NOTE: Be careful not to over-inflate the bag. You should be able to depress your finger in to a depth of about 2" when fully inflated.



FREQUENTLY ASKED QUESTIONS

Question: "Is there any maintenance I need to do for this?"

Answer: Before each use, you should always double check to make sure there are no holes and base is full of water. Question: "Something was missing from the packaging," "I need to purchase a replacement part" or "I discovered a damaged piece. What should I do?"

Answer: Contact customer service. You must have your proof of purchase and/or order confirmation available to be considered for warranty replacement. You must report missing pieces within 30 days from the date of purchase. Question: "How should I clean my bag?"

Answer: you should clean this equipment a solution of warm water and non-corrosive and/or non-abrasive soap. Dampen a rag with this solution an swipe completely dry before using.

Thank You Coupon!

As a way of saying thank you for purchasing one of our products, here is a 10% OFF coupon for your next purchase at

www.PureFun.net

Use Code: GQBRANDS10 at Checkout

