



Original Pleated Paper and Fabric Shade

Original Persianas Plisadas de Papel y Tela

Use Instructions

Instrucciones de Uso



1



Trim to desired width
using an utility knife

Corte a la medide requerida con
un cuchillo o navaja


2



Peel adhesive liner

Despegue la cinta adhesiva

3



Press firmly across width
of shade to install

*Overlap two or more shades for
larger widths

Pegue y presione firmemente
para instalar

*Para ventanas mas grandes junte dos o mas
persianas



Use the two included clips to
raise and lower the shade

Utilize los clips incluidos para subir y
detener la persiana



Redi Shade Customer Support: 1-888-608-6611