


lifesmart® is a registered trademark of
Supply Chain Sources LLC., All Rights Reserved.

Customer number:
SC-D027

**ATTACH YOUR RECEIPT HERE**

Purchase Date _____ Serial Number (located on back of unit) _____



Questions, problems, missing parts? Contact technical support department at
657-341-0362, 9:00 a.m. - 5 p.m., PST, Monday - Friday or visit us Online at
www.lifesmartcomfort.com
Please have your model and serial number ready

TABLE OF CONTENTS

Package Contents 3

Safety Information 4

Frequently Asked Questions 6

Troubleshooting 6


Preparation 6

Operating Instructions 7

Care and Maintenance 8

One-Year Limited Warranty 9

PACKAGE CONTENTS




PART	DESCRIPTION	QUANTITY
A	Humidifier Body	1
B	Water Tank	1
C	Control Panel (preassembled to [A])	1
D	Humidification Nozzle	1

SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, operate, or install the product.

IMPORTANT SAFETY INSTRUCTIONS

 **WARNING:** POTENTIAL ELECTRICAL HAZARD IF NOT ADHERED TO. When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- **DO NOT carry Water Tank by handle when it is filled with water. It is advisable to carry filled Water Tank with two hands.**
- **DO NOT operate outdoors. This humidifier is intended for indoor use only.**
- Always have water in the Water Tank when operating the unit.
- Use only clean, cool tap water to fill the Water Tank (filtered or distilled water is recommended to avoid white dust if tap water is too hard; demineralization filters are also available for purchase).
- **DO NOT use hot water.**
- Be sure that the Water Tank Cap is firmly tightened on Water Tank. Always have the Mist Lid in place while the unit is operating. Place the humidifier so the mist aims away from children, walls, furniture and electrical appliances.
- Use only a 110-120VAC outlet. ALWAYS plug and unplug unit with dry hands to avoid electric shock.
- Never operate the unit with a damaged cord or plug.
- Always place the unit on a smooth, flat, lint-free, non-metallic, waterproof and level surface and position unit away from direct sunlight. Keep the cord away from heated surfaces and areas where it could be walked on or tripped over. Unplug the unit when not in use and whenever you clean or move the unit.
- Do not add medication of any type into the Water Basin or Water Tank. Do not cover any openings on the unit or insert objects into any openings.
- The unit should not be left unattended in a closed room as the air could become saturated and leave condensation on walls or furniture. Leave room door partly open when humidifier is being operated.
- When cleaning the inside of the humidifier, keep water away from the Fan Vent. Turn off and unplug the humidifier to wipe the exterior (except the electrical controls) with a damp cloth. Humidifier requires regular cleaning. Please refer to the CLEANING INSTRUCTIONS in this manual.
- Do not tilt or tip the humidifier or attempt to empty or fill it while it is in operation.
- Do not use a detergent to clean any parts of the unit that contain water. Detergent film dissolved in the water supply can interfere with the output of the unit. Instead, always use white vinegar mixed with water to clean the humidifier.
- This Fan is not intended for use in wet or damp locations. Never locate a Fan where it may fall

SAVE THESE INSTRUCTIONS

SAFETY INFORMATION

⚠ WARNING: Read and understand all instructions. Failure to follow all instructions listed below may result in electric shock, fire or serious personal injury. The warnings, cautions, and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the user that common sense and caution are a factor which cannot be built into this product, but must be supplied by the user.

⚠ CAUTION: CAUTION: A short Power Supply Cord is provided to reduce the risk of personal injury resulting from becoming entangled in or tripping over a longer cord. Extension cords are available from local hardware stores and may be used if care is exercised in their use. If an extension cord is required, special care and caution is necessary. Also the extension cord must be (1) marked with an electrical rating of 125 V and at least 13 A., 1625 W., and (2) the cord must be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or accidentally tripped over.

ELECTRIC POWER: If the electric circuit is overloaded by other appliances, your humidifier and/or appliances may not operate properly. The humidifier should be operated on a separate electrical circuit from other operating appliances.

POLARIZED PLUG: This humidifier has a polarized plug (one blade is wider than the other). As a safety feature to reduce the risk of electrical shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

SAFETY PRECAUTIONS:

Although your humidifier is easy to operate, for your safety, the below warnings must be followed:

- Do not place the humidifier near a heat source.
- Never leave the humidifier unattended while connected to the electrical outlet.
- To avoid any accidents, never cover the Mist Lid when the humidifier is in operation.
- Use the humidifier on a smooth, flat, lint-free, non-metallic, waterproof, and level surface away from water.
- Do not unplug from the wall socket by pulling on the supply cord.
- The humidifier must be unplugged:
 - Before either filling or emptying the Water Basin and/or Water Tank.
 - Before any cleaning or maintenance is performed.
 - After each use.
 - If it appears to be faulty.

THIS PRODUCT IS INTENDED FOR HOUSEHOLD USE ONLY

SAVE THESE INSTRUCTIONS

TROUBLESHOOTING

PROBLEM	SOLUTION
Humidifier power indicator light is staying red and not turning green:	<ol style="list-style-type: none">1. Ensure that the water tank cap is secured properly to water tank.2. Empty out water in humidifier base. Place filled water tank on to empty humidifier base.3. Clean Water Level Sensor: To clean the water level sensor, snap off the plastic cap from the pin. Remove the water level sensor float and clean by wiping the parts with a soft, damp cloth. Replace the parts by first putting the water float onto the pin and replacing the plastic cap on pin.
If humidifier does not have any power:	<ol style="list-style-type: none">1. Ensure unit is properly plugged into a power outlet.2. Check that the Control Knob is turned to the ON position.3. If Power On indicator light does not come on, contact technical support
If there is a strange odor	<ol style="list-style-type: none">1. Clean the Water Tank with the water and vinegar solution and rinse with clean water.2. Leave the empty Water Tank open for some time (without the Water Tank Cap attached) in a cool place.
The power indicator light is green, but there is no mist being emitted:	<ol style="list-style-type: none">1. Check that there is water in the Water Tank.2. Make sure that nothing is blocking the Mist Lid.3. Check that the Fan Vent on the bottom of the humidifier is not blocked.4. Empty and rinse the Humidifier Base with cool tap water.5. Check for possible mineral deposits on the Water Level Sensor and Nebulizer.
White dust appears and settles outside the humidifier:	<ol style="list-style-type: none">1. Your area tap water may have too many minerals. Change to filtered or distilled water or purchase a demineralization filter cartridge.

PREPARATION

⚠ CAUTION: DO NOT operate the humidifier without water in the Water Tank.

⚠ CAUTION: DO NOT plug or unplug the Power Cord with wet hands as electric shock could occur.

CHECK HUMIDIFIER PLACEMENT: Place the Humidifier on an elevated, non-metallic, lint-free, waterproof, level surface at least 2 feet above the floor.

- DO NOT place the humidifier on carpet or a towel. The fan vent is located on the bottom of the humidifier base. The fan vent MUST NOT be obstructed.
- DO NOT place the humidifier on a wood surface or near furniture that can be damaged by too much moisture.

CHECK WATER LEVEL SENSOR: Make sure that the Water Level Sensor is secured properly and not obstructed.

OPERATING INSTRUCTIONS

1. Insert the power plug into the socket, it will hear "B B" sounds 2 seconds.
2. When the power plug is inserted into the socket and there is no water in the water tank, the power indicator light is red. When the water in the water tank exceeds the standard of the water level, the indicator light is not displayed.
3. Operation sound, Each operation means one B sound. When power off, the sounds like double B.
4. Humidification: when the power button is pressed once, "B" sounds one time, then the green LED light starts to humidify at the same time. By the way, the humidify is highest way.
5. There is +/- key on the machine. Press once "-"key, key sound like "B"loud . become mid-range operation, Press "-"again, , the machine become low gear operation.
6. Press the button again in the low gear and do not switch the gear position without the operation sound. Under the low gear operation, press the "+"key, sound like "B" loud, the machine will shifts mid-range operation. Press the "B"key again, the machine will turn into high-range operation. Now you press the button again when is the high grade, and it will not switch gears and there is no operation sound.
7. Stop, when the machine is working, if press one time power key, sound "B" twice, the machine will be stopped after one minute of of working status. The fan will continue to turn for minute and stop. When the machine is shortage of water, if shortage in the humidification operation ,the power indicator changes from green to red and humidification function stop, the fan continues stop after one minute.

CARE AND MAINTENANCE

⚠ IMPORTANT: DO NOT leave water in Water Tank or Humidifier Base when unit is not in use as it may result in the buildup of mineral deposits and bacteria that can inhibit the output efficiency of the humidifier. If water remains in the Water Tank for more than a day or two, bacterial growth is possible.

It is important to keep ultrasonic cool mist humidifiers clean. Cleaning and disinfecting on a regular basis is important for maintaining the performance of your humidifier

DAILY MAINTENANCE

1. Always turn off and unplug from outlet before cleaning.
2. Empty water from the water tank and humidifier base daily.
3. Wipe and dry humidifier base with a clean, dry cloth or paper towel.
4. Replace the water tank.

WEEKLY MAINTENANCE

1. Always turn off and unplug from outlet before cleaning.
2. Empty water from the water tank and humidifier base.
3. Fill the water tank with about a half-gallon of warm water. Add 2 Tablespoons of white vinegar. Shake vigorously and let sit for 20-30 minutes. Shake vigorously again and empty the water. Rinse water tank.
4. Make similar white vinegar/water solution. Pour into humidifier base. Let sit for 20-30 minutes, and then empty. Rinse humidifier base. Wipe dry with a clean, soft cloth.
5. Wipe the exterior surface water tank and humidifier base with a soft, dry cloth.

NEVER IMMERSE HUMIDIFIER BASE IN WATER.

END-OF-SEASON MAINTENANCE & STORING YOUR HUMIDIFIER

1. Always turn off and unplug from outlet before cleaning.
2. Empty water from the water tank and humidifier base.
3. Disinfect water tank and humidifier base with the white vinegar and water solution.
4. Make sure that water tank has air dried without the water tank cap secured.
5. Make sure the humidifier base and water tank are completely dry before end of season storage. Store the humidifier in a cool dry place.
6. DO NOT place any heavy items on top of humidifier during storage as this may result in possible damage of the humidifier.
7. Store the cord in a clean, dry location away from metal objects. Always check the plug before use to ensure metal items have not become attached.

A NOTE ABOUT HUMIDITY

- It is best to keep the humidity level at about 40%-50% of relative humidity.
- In cold weather, windows and even some walls may fog or develop frost from excessive indoor humidity. If this occurs, reduce the mist output setting to avoid damage from condensed water dripping onto windowsills.
- Too much humidity in the room may allow moisture to accumulate on surfaces where bacteria and fungi can grow. Moisture that gathers may also damage furniture and walls, especially wallpaper.
- To reduce excessive humidity, especially in small rooms, leave the room door open and adjust the mist intensity control setting.

ONE-YEAR LIMITED WARRANTY

The manufacturer warrants this product against defects in materials and workmanship on functional parts, for a period of 1 year from the original date of purchase. Your sales receipt showing the date of purchase of the product is your proof of purchase. Keep it in a safe place for future reference. This warranty is subject to personal use only, commercial or rental applications will not be covered.

This product is made with the highest quality materials and is warranted to be free from defects in materials and workmanship at the time of purchase. This limited warranty applies to products manufactured or distributed by the manufacturer, are delivered in the continental United States or Canada and extends to the original purchaser, or gift recipient. This warranty becomes valid at the time of purchase and terminates either by the specified time frame listed above and/or owner transfer. Any refunds or monetary compensations must be claimed through the place of purchase (retailer), and not through the manufacturer. Any extended warranties (warranties that cover above and beyond this manufacturer warranty) that are sold through a retailer or third party, are not directly correlated with this products' limited warranty, and may be redirected to said retailer or third party for coverage.

This warranty extends through the manufacturer of the product, and covers functional parts only. Cosmetics are not covered, unless unequivocally determined it is a workmanship defect. Shipping damage should be addressed with the shipping company, retailer, or place of purchase, not the manufacturer unless the manufacturer was the direct shipper.

The manufacturer's sole obligation under this warranty shall be limited to furnishing the original purchaser replacement parts for units deemed repairable by the supplier's warranty department. The purchaser is responsible for insuring any parts shipped or returned, if desired. The purchaser is responsible to prepay any shipping charges (both ways) including, but not limited to taxes and duties. All exchanged parts and products replaced under this warranty will become the property of manufacturer. The manufacturer reserves the right to change manufacturers of replacement parts or products for use, in order to cover any existing warranty.

The purchaser may be asked to provide the supplier with proof of purchase documents (including the date of purchase) if requested. Any evidence of alteration, erasing, or forgery of proof of purchase documents will be just cause to VOID this limited warranty. Products, in which the serial number has been defaced or removed are not eligible for warranty coverage.

This warranty does not apply if the unit has been subject to negligence, fabrication, misuse, abuse, or repairs, alteration by non-manufacturer authorized personnel, inappropriate installations, or any case beyond the control of the manufacturer. Examples of warranty invalidation may also include, but are not limited to:

- Use of lacquer or paints in (and around) the product
- Product placed on non-approved surfaces
- Electrical requirement deficiencies
- Use on extension cords/timers/surge protectors/GFCI
- Outdoor applications
- Normal wear/tear/weathering
- Pet/consumer accidents
- Purchases from dealers unauthorized by the manufacturer (Authorization in writing)

The manufacturer shall not be liable for any loss due to use (or misuse) of the Product or other incidental or consequential costs, expense or damages without irrefutable foundations. Under no circumstances shall the manufacturer or any of its representatives be held liable for injury to any person or damage to any property, however arising. Any implied warranty shall have duration equal of the applicable warranty stated above. Specifications are subject to change without notice or obligation.

This limited warranty gives the original purchaser specific legal rights. Other rights may vary from state to state.

Any instructions or warranty included in this manual may be subject to change without notice. For the most up-to-date instructions and warranty information, please contact us or visit our website.

PLEASE REMEMBER TO REGISTER YOUR WARRANTY:
web: www.lifsmartcomfort.com
email: csf@scsources.com

Printed in China

lifsmart® is a registered trademark
of Supply Chain Sources., All Rights Reserved.