# MANUAL INSTRUCTION

**TV Stand** 

H21017





#### **Indoor Furniture**

We are a professional furniture provider with top-notch factories and outstanding designs, Our mission is to provide consumers with new lifestyles. By collecting consumer feedback, we constantly improve our products and create more choices for consumers.

If you want to create your space, We are an ideal choice.

Always.



# **WARNING**

All the TV Stands have passed strict quality inspections before delivery . Read this manual carefully to ensure proper usage

Ensure that all parts and hardware are available before beginning assembly

#### **NOTICE**

- 1. Children are not allowed to operate.
- 2. Faster installation is possible with power tools.
- 3. Do not pull the door vigorously to prevent the storage cabinet from tipping over.
- 4. Please attach the storage cabinet to the wall with an anti-tip device after installation is complete.
- 5. When using the storage cabinet for the first time, please keep it in a ventilated environment to allow the smell to fully evaporate.
- 6. When placing the partitions, please make sure the nails are firmly installed to prevent the partitions from falling off.
- 7. If any parts are missing, broken, damaged or worn, discontinue use of the product until repairs are made and/or factory replacement parts are installed.
- 8. Do not use this product in a manner inconsistent with the manufacturer's instructions, as this may void the product warranty.
- If accessories are missing, please contact customer service for communication in time, we provide 7x24 hours customer care.
- 10.Do not use any attachments or accessories other than the original factory attachments and accessories.
- 11. Do not alter this equipment. Any alteration will create a safety hazard.

#### WARNING

The product must be assembled by adult before use. Serious or fatal injury may occur from unexpected assembly or use.

- 1. During the assembly process, keep all parts away from babies or children.
- Always securely fix this product to the wall. Make sure the wall area to be drilled is free from hidden electrical wires, water and gas pipes.
- 3. Use of tip-over restraints may only reduce, but not eliminate the risk of tip-over.
- 4. Unless specially designed to accommodate, do not set heavy objects on top of this product.
- 5. Place the heaviest items on the lowest shelf.
- 6. Never allow children to climb or bang on drawers, doors or shelves.


# I TOOLS REQUIRED





2 Persons Assembly


#### **PARTS**
































#### **HARDWARE**






















#### PRODUCT ASSEMBLY TV Stand


1. Use 4 bolt "F" secure part ① to part ③ with hex key "G" as per diagram 2. Use 4 bolt "D" to secure the middle of part ③ and the both sides of part ② as per diagram.



Using 10 bolt "E"secure the Installed part (1) (2) (3) to part (5) with hex key "G" as per diagram E.




Turn the assembled parts in step 2 face up, and secure 8 cam bolt "c" into part (5) with Philips head screwdriver as per diagram.



PART	NO.	QTY.
87. A.	С	8


Note: If the white plastic is not pressed into the available tools can be gently knocked down.

Install 2 cam bolt "C" to the corresponding hoes of part 1 and in the same way, Install 2 cam bolt "C" to the corresponding hoes of part 2.



PART	NO.	QTY.
\$2.50 B	С	8

4.2 Connect part (9) and part (19) with 2 cam lock "B", and similarly connect part (19) and part (8) with 2 cam lock "B", locking the "B" clockwise.






Use 2 wooden dowel "A" to connect part @ &part @ with part @. 4.3 Use 2 wooden dowel A 10 confidence part (1) Two People cooperate, and then use 2 wooden dowel "A" to connect part (1) &part @with part 5.

Align the holes on the bottom of part®&part® with 4 cam lock"C"above the part, as per diagram.

Then put 4 cam lock "B"into the corresponding holes of part ® &part 9, and tighten cam lock "B" clockwise.


NOTE: The slotting direction of part®&part® is adjacent to the slot of part when installed correctly!



PART	NO.	QTY.
	Α	4
	В	4

NOTE:For aesthetics, when installing part 10 , place the two large holes towards the inside of the cabinet.

- 1. Align the holes on the bottom of the part@&part@with the 4 cam bolt "C" above the part (as per diagram.
  - 2.Put 4 cam lock"B"into the corresponding holes of part 6 & 7 part, and tighten cam lock"B"clockwise.



PART	NO.	QTY.
	В	4

NOTE: When installing, pay attention to distinguish between part ⑦ and part ⑥, part ⑦ is on the left side, and part ⑥ is on the right side.


Note: The slotting direction of part ® & part ® is adjacent to the slot of part when installed correctly!

Snap the two part ® down to the bottom along the card slot.


Note:

1. The bottom of part ③ also needs to be snapped into the slot of part ⑤.

2. For aesthetics, the white side of part ③, towards the inside of the cabinet: the yellow side of part ③ towards the outside of the cabinet




7 Screw 10 cam bolt "C" into part 4 corresponding holes as per diagram.



PART	NO.	QTY.
<b>*</b>	С	10

Put Two "A" into the holes of part (1) and part (1), then put "4" into the corresponding position and lock it clockwise with 10"B", note that "13" should be stuck into the 4 slots.

Note: Pay attention to lightly put, do not violently press.



PART	NO.	QTY.
	Α	2
	В	10


Part (3) needs to be snapped into the slot of part (4). While installing part (4), the hardware of part (5) needs to be snapped into the corresponding holes of part (4) & part (5).

**PART** 


**8** 

н

1.Put 8"H" into the corresponding holes.
2.Then put the glass laminate(part (4)) into the cabinet.
The cabinet installation is completed.




For beauty, you can cover the exposed holes with "I" according to your needs




### PRODUCT ASSEMBLY Steps to install the fireplace into the cabinet

NOTE:Dear customer, if you purchase a TV stand & fireplace set, the package for the fireplace and the package for the TV stand will be delivered separately. If you purchase only the TV stand, the fireplace is not included.

Put the fireplace into the cabinet from the back until the front is against the board.





2 1Unscrew the two silver screws at the bottom of the fireplace 2. Then connect the iron sheet to the fireplace and the cabinet according to the corresponding hole position.




3


1.Put the light strip wire through the hole (one long wire and one short wire). 2.Put the long one on the side farther from the fireplace wire, the short one on the side closer ti the fireplace wire.





Tear off the double-sided tape of the light strip and stick it on the board.





Hold the light strip with the clip and lock the screw.

# HELP CENTER

Question about your product? We're here to help. Visit us at:











Chat Support

**Product Inquiry** 

Orders FAQ

Product Assembly Returns & Refunds

#### We Stands Behind the Quality of Their Furniture

If you have any issues with your item please let us know! We will always do our best to come up with a solution that you will be happy with.

 ${\it Please get in touch with our customer service team before returning the product.}$ 

And pls do not throw the original box(es) if you have not finished assembling or confirmed no quality issues.

Length of return period:

Items can be returned within 30 days of purchase.

In the meanwhile, everything you purchased from us comes with a one-year warranty.

Who is responsible for the return shipping fee:

We will cover the return shipping fees if:

- 1. Your item has a manufacturing defect in its materials or workmanship. For example, torn wicker or misaligned screw holes. We will send you a prepaid shipping label after photos are sent.
- 2. Your item has been damaged in transit. For example, glass is broken or wicker is damaged. We will send you a prepaid shipping label after photos are sent.
- 3. You receive the wrong box(es) due to a warehouse error. We will send you a prepaid shipping label after photos are sent of the wrong SKU numbers on the outer box(es).
- 4. One or more boxes are lost in transit. We will send you a prepaid hipping label if you no longer want the item.
- \*However, we still hope to work with you for a better solution instead of a return. Please don't hesitate to contact our customer service team.

Customer will cover the return shipping fees if:

- 1. You don't like the product(s) after receiving the box(es).
- 2. You no longer need the product(s) but you have received the box(es).
- 3. You buy the product(s) by mistake but you have received the box(es).
- 4. Order/Shipment cancellation failed and you have received the box(es).

#### **Return Request**

In order to get a full refund as described in this return policy, all items must be: (1) In a brand new/unused condition, please provide photos before and after packaging. (2) When returning, all accessories and parts are firmly packed in all original packaging. If your return does not meet the requirements, you may not get a full refund.

When will I be refunded?

The refund is released once the goods have been returned to our warehouse.

What if the product is damaged/defective outside of the valid return period?

We want you to be a happy customer. Please reach out to us by email and we will come up with a solution to make sure you are satisfied.