

尺寸：210X145MM

材质：说明书封面铜版纸-200G+亚膜

说明书内页铜版纸-128g



C: 77%

M: 33%

Y: 11%

K: 0%

AMEIFU



EPA EST.NO. 101169-CHN-1

✉ support@myameifu.com

☎ 1-833-638-3838

🌐 www.myameifu.com

Made in China

AIR PURIFIER USER MANUAL

Model: F1

Double Side Filtration System

Perfect for Large Rooms

Quiet Operation

100% Ozone Free

✉ support@myameifu.com

☎ 1-833-638-3838

🌐 www.myameifu.com



AMEIFU



CUSTOMER SERVICE

Our customer service team is always ready to assist you if you have any issues or concerns.



Filter need be replaced within 3-6 months.
About filter and more surprise, please scan
above and contact!



- ✉ support@myameifu.com
- ☎ 1-833-638-3838
- 🌐 www.myameifu.com

Content

READ AND SAVE THESE INSTRUCTIONS	01
PRODUCT OVERVIEW	06
8 STAGE FILTER	07
OPERATION INTRODUCTION	08
OPERATION PANEL INTRODUCTION	09
AROMATHERAPY FUNCTION	10
OPERATING THE AIR PURIFIER	11
INSTALLING & REMOVING FILTERS	15
CARE & MAINTENANCE	16
PACKAGE CONTENTS	18
TROUBLESHOOTING	19

READ AND SAVE THESE INSTRUCTIONS

Please follow the instructions manual carefully to avoid personal injury or damage to the product.

WARNING/ATTENTION

WARNING

Please read the important safeguards carefully before using this air purifier.

ATTENTION

It reminds us that misusing or mishandling may cause hurt.



FORBID

The operation cannot be performed or forbidden.




FORCE

A certain operation should be performed (mandatory).

READ AND SAVE THESE INSTRUCTIONS

WARNING



Please supervise your children and prevent them from touching or using appliances.



AVOID WET

Do not handle the plug with wet hands to avoid electric shock.



NO DISASSEMBLE

Do not disassemble, repair, or reconstruct the appliance to avoid an electric shock, fire, or injury. Contact the seller for item repairs.



FORBID

Check if the voltage indicated on the appliance corresponds to the local power voltage before you connect the appliance. Using a non-standard power cord may cause a fire due to overheating.

READ AND SAVE THESE INSTRUCTIONS



UNPLUG PLUG

Unplug the power plug when cleaning; otherwise, the air purifier may start suddenly, causing injury or electric shock.



Please do not put foreign objects such as needles, iron wires, or metal objects into the air outlet and suction vent. It is easy to cause electric shock and injury.



FORBID

Please do not damage, twist, stretch, or process the power cord and power plug in a way that causes excessive distortion. Additionally, do not place heavy objects on them or bundle them together.

Using damaged power cords and power plugs can easily result in electric shock, short circuit, fire, and other accidents. If you need maintenance for the power cord and power plug, please consult the store where you purchased it.



FORCE

Make sure the power plug is inserted all the way to the socket. A plug that is not fully inserted can cause a fire due to electric shock and heat generation. Please do not use damaged plugs or loose sockets.

READ AND SAVE THESE INSTRUCTIONS

⚠ WARNING




FORBID


Please do not start this machine when using spray insecticide indoors. Otherwise, the chemical components will accumulate inside the machine and then be released from the air outlet, which is harmful to human health. After using pesticides, please allow for adequate indoor air circulation before using the machine.



Avoid inhaling flammable substances such as flammable cigarettes, incense, etc., as they can easily ignite and cause a fire.




Please do not use it in places with high temperature, humidity, or water, such as bathrooms. Otherwise, it is easy to cause electrical leakage, electric shock, fire, and other consequences.




When unplugging the power plug, please do not hold the power cord. You should hold the power cord plug before pulling it out. Otherwise, the power cord may be short-circuited or disconnected, resulting in a fire or electric shock.

READ AND SAVE THESE INSTRUCTIONS



Please do not wipe with alcohol or organic solvents, and do not spray insecticides. Otherwise, the product may break, short-circuit, or cause electric shock, resulting in injury or fire.



When using a gas appliance at the same time, please pay attention to ventilation; otherwise, it may cause carbon monoxide poisoning. **Machines cannot remove carbon monoxide.**

Unplug the product immediately if any of the following situations occur:

- Any switch does not operate.
- The circuit is shorted.
- The power cord or plug is abnormally hot, there is a burning smell, or there are abnormal sounds and vibrations.
- There are any other abnormal phenomena or malfunctions.

If the power cord is broken, you must contact the product agent, maintenance service center, or qualified technicians to replace and repair it to prevent any danger.

PRODUCT OVERVIEW



8 STAGE FILTER

The filter consists of a pre-filter, HEPA, and activated carbon. The pre-filter filters large particulate solid pollutants to ensure the service life of HEPA. HEPA efficiently removes PM2.5, with a removal efficiency greater than 99.97%. The activated carbon layer effectively removes gaseous pollutants such as formaldehyde, benzene, VOC, and keeps the air clean



Air Cleaning System

Pre-filter: Filters out hairs, pet hairs and fibres.

True HEPA Filter: Filters cotton wool, pet dander, dust and others.

Active Carbon Filter: Filters smoke, pet odor, cooking smell and VOCs.


OPERATION INTRODUCTION

! BEFORE OPERATING THE AIR PURIFIER:

1. Carefully remove your air purifier from box and plastic bag.
2. Select a firm, level, and flat location for the air purifier.
*For proper air flow, locate the unit at least 1 foot from any wall or furniture.
3. Before using, remove the plastic bags covering the filters.
4. Plug the power cord into an AC 100-240V outlet.



OPERATION PANEL INTRODUCTION



Note:

1. The remote control is powered by a CR2035 battery.
2. Please **pull out the insulation sheet** at the bottom before using the remote control, and press "Power On" button of the remote control for 3 seconds within 10 seconds after the machine is connected to match it.

AROMATHERAPY FUNCTION

A replaceable aroma pad is included in the aroma tray on the top air outlet, where you can put a few drops of essential oil (**not included**). This allows you to breathe in fresh air and relax yourself!

How to add the essential oils?

- 1.Remove the aroma tray cover.
- 2.Add a few drops of an essential oil - more or less may be used depending on your preference of aroma strength.
- 3.Install the tray cover onto the unit.

Notice:

1. Please do not put essential oils directly into the HEPA filters, as it can damage the device and reduce filter efficiency.
2. The fragrance of the aromatherapy is determined by the concentration of essential oils.
3. Due to the small size of the aromatherapy sponge pads, it is recommended to use the aromatherapy function in smaller rooms to ensure the effectiveness of the aromatherapy.




OPERATING THE AIR PURIFIER

On/Off Button

Gently touch the power button to turn the device on and off. After turning it on, the air quality light will light up, and the wind speed is in low mode. Press the power button again to turn off the device.

Note: It will enter 60 seconds of preheating when you turn on the air purifier for the first time. At the same time, the indicator light will flash green, blue and red in a cycle. The indicator light will flash one of three colors(green, blue and red) to display the current air quality. While, the screen also displays the PM2.5 value.



OPERATING THE AIR PURIFIER

Auto Mode Button


Touch the "Auto" button, the device starts in auto mode, the auto mode icon on the display screen lights up, and the device automatically adjusts the air quality light color and operating wind speed according to the detected ambient air quality.

Ambient Air Quality	Air Quality Light Color	PM2.5	Display Screen
Preheat	   light flashing	/	  
Good	 light	≤75	
Minor pollution	 light	75–150	
Severe pollution	 light	≥150	

OPERATING THE AIR PURIFIER


Wind Speed Button

Touch the wind speed button to adjust the wind speed.



Timer Button


Touch the timer button to set the timer duration (2/4/6/8 hour).



OPERATING THE AIR PURIFIER


Light Control Button

Press this button once, and the brand air quality light will light off, press this button twice, and the panel light will light off, press this button the third time, and the brand light and panel light will light on.



Child Lock Function

Long press the child lock button for 3-5 seconds, and the device will turn on the child lock. The child lock icon will light up to indicate that the child lock is activated. At this time, all buttons on the device will be inactive. To deactivate the child lock function, simply long press the child lock button again for 3-5 seconds. The child lock icon will turn off, and all buttons will return to their operable state.




INSTALLING & REMOVING FILTERS



Filter Replacement Indicator

The filter replacement icon on the display lights up indicates it is time to replace the filter.

Follow the instruction below to change filter and reset the program.



The operation of replacing the filter on the other side is the same.


1. Please clean it once a month using a soft brush or a vacuum cleaner to remove larger hair and dust particles from the surface of the filter. **(Do not wash it)**
2. The filter needs to be replaced every **3-6** months for better purification results.

CARE & MAINTENANCE



Please unplug the power cord before maintaining the machine.

- Wipe the body shell with a damp cloth and then dry it.
- If the outer shell is very dirty, neutral detergent can be used to dilute it before cleaning.
- Please do not use the items shown in the picture on the right for washing (otherwise it will easily cause deformation and discoloration of the body).



Cleaning Tips:

1. Turn off and unplug the appliance if you are cleaning it or when it is not in use for a long time.
2. Refer to the filter cleaning and maintenance frequency: once a month.
3. Never use abrasive objects that could damage the appearance of your appliance.
4. Clean the appliance with a soft, dry cloth.
5. Never use abrasive cleaning agents, scourers, acetone, or petrol to clean the appliance.
6. Never immerse the motor base in water or place it under running water to avoid the risk of electric shock.
7. The filter is easily damaged and deformed. Please do not press or pull it forcefully during cleaning. If it is damaged, replace the filter with a new one.

Maintenance

1. Replace the filter every **3-6** months. The replacement cycle may vary depending on the area and ambient air quality. The filter replacement cycle may be reduced in heavily polluted areas, smoking areas, etc. When the filtering effect is poor, please replace the filter.
2. Cleaning: Wipe the outer surface, the air inlet, and outlet with a wrung soft cloth. Do not clean the surface with abrasive cleaning agents.
3. When not in use for a long period: unplug the power adapter, clean the outer surface and filter. Put it in a plastic bag and store it in an area with low humidity.

Warning


1. Do not wash or spill liquid on this product.
2. Keep your hands and fingers away from the high-speed wheel component rotating in the purifier. Avoid foreign objects entering the unit's air vent, as it may cause heat or damage to the unit.
3. Do not block the air inlets and outlets. There should be a certain space around the air purifier.
4. Children should not play with the air purifier. This appliance should be used by adults.
5. In order to improve the purification effect, close the doors and windows when using the unit (to avoid carbon monoxide poisoning, properly ventilate when using a combustion unit).
6. Please do not use any power adapter other than the one provided with the air purifier.
7. Do not use the appliance in wet, moist areas such as bathrooms, steamy kitchens, or near swimming pools and humidifiers, as it may cause an electric shock.




Air Purifier*1



Remote Control*1



True Hepa Filter*2



Adapter*1



User Manual*1

Parameter:

product name	Air Purifier	Product model	F1
Rated power	55W (±10%)	Input voltage	AC120-240V
Product weight	10.36lb	Product size	16.14*11.81*6.89in
Power cord length	1.5m/59in	CADR	400 m³/h (±10%)
Filter Size	11.41*10.31*1.81in	Filter replacement time	2160hs (±10%)

Troubleshooting

Abnormal phenomenon	Inspection methods	Solutions
The air purifier does not work	Is the power cord plug plugged in properly?	Plug the power cord plug in correctly.
	Is the filter cover properly covered?	Recover the filter cover.
Difficult to remove odor	Is the odor of the usage environment particularly strong? Long term continuous purification is required	It is recommended to ventilate before starting the machine.
	Is plastic bag of the filter is removed?	Remove the plastic bag of the filter.
	Has the filter reached its use time?	Replace the filter.
The air purifier is noisy	Has the plastic bag of filter removed?	Take out the filter and remove the plastic bag.
	Has the filter reached its use time?	Replace the filter.

Troubleshooting

Abnormal phenomenon	Inspection methods	Solutions
Can't feel the fragrance	Is the essential oil been added?	Add the essential oil
	Is the fragrance level of essential oil is low or low-quality?	Choose essential oils that are good quality and have a strong fragrance
	If far away from the air purifier?	Try positioning the air purifier closer to you for a stronger scent.
 is still on after replacing the filter.	Has the machine been reset by pressing the filter replace indicator and reset button after replacing the filter?	Reset the filter replace indicator and reset button for 3 seconds after replacing the filter.

If the problem cannot be solved after completing the above checks, please unplug the power cord and contact the agent for repair.

Note: The adapter and remote control are placed at the bottom of the machine, please take them out before use.