

USER'S MANUAL

MIRANDA SERIES FOLDING ADIRONDACK CHAIR & CUP HOLDER



Guide of Manual

- ★ Thanks for your choice. We will do our best to provide customer service for everyone.
- ★ Please check to make sure all parts are included as stated when you unpack. If there are parts missing or wrong, please contact us, we will expeditiously provide reissue accessories, compensation or other services.
- ★ Instruction should be read carefully. But the manual may not cover every detail of all possible situations and steps. Please contact us if further information and help are needed. We will respond in a timely manner.
- ★ Please be patient that the other items are on the way if you buy more than one product.

Care and Maintenance

- Use a soft, clean cloth that will not scratch the surface when dusting.
- If you run into scratches problems, we suggest you erase the scratches by knife.
- This item could be cleaned with soap and water. Be sure to avoid harsh solvents and abrasives.
- Periodically (every 90 days) make sure the screws are fully tightened.

Material

• 100% HDPS

Warning

- It's kindly advised to assemble this product on a carpeted floor to protect it from being scratched.
- Small parts are included. Please keep the product away from children while assembling. Do not let children play or jump on the product.Do not stand on the item or use as a step ladder.
- Please pay attention to the sharp corners during assembly.
 We recommend the use of gloves to prevent the undesired injury.
- Prior to use, please check to see if there's any loosening screw or part. Make sure that each screw and part is correctly installed and securely fastened.
- Usually it's unnecessary to use electric drill. Please at a low gear if you need.

Resists Pest & Rough Weather


These all-weather items can be stored outdoors year-round. Perfect for people who lives in a wet climate or lives on the coast where humidity and moisture will be an issue all year.

Max weight capacity


300lbs [Do not stand on the item]

Parts List & Assembly Instruction


- 1.Make sure all parts are in the package.
- 2.Do not tighten all bolts until them haven been installed in corresponding locations.



A x 1PC Back



B x 1PC Seat




C x 1PC Left Arm



D x 1PC Right Arm



E x 2PCS Connecting Pivot



F x 2PCS Front Legs




G x 1PC Front Support




H x 1PC Seat Brace




I x 1PC Cup Holder







Step 2 Notice:

- •Bolts (BB) always needs to be used with both nuts and gaskets. You must fix the nuts with a spanner and tighten the screws with an Allen wrench at the same time.
- •Note that the gaskets should always be used between the two parts. (As shown as the picture)






Step 4




Step 5




Notice:

- •Bolts(CC) (DD) always need to be used with gaskets. Note that the gaskets should always be used between the two parts.
- •Be sure to adjust bolts (BB) (CC) (DD) to 80% tightness before use. On the one hand, fully tighten will leave you with a stumbled folding. On the other hand, loose bolts will cause instability. It is best to readjust the tightness if you fold the chair frequently.



•There should be a space between the bolts (CC) or (DD) with the product for folding.





How to Fold? The chair can pivot to fold by pushing the back forward and rotating the E part.