
Assembly Instructions

Item: ACCENT CHAIR SKU: W2336P251803&04&06



1. Important Safeguards



Read these instructions carefully and retain them for future use. If this product is passed to a third party, then these instructions must be included.

When using the product, basic safety precautions should always be followed to reduce the risk of injury including the following:

A CAUTION Risk of injury!

- Product can tip over! Do not let children climb on or play with the product.
- Always use the product on a firm, level ground.
- Do not stand on the product or use it as a step ladder.
- Periodcally check to see that all bolts, screws and knobs are firmly screwed. Tighten them if any are loose.
- Stop using the product at first sign of damage or if parts become detached.
- Keep the fire or all sharp objects away from the product.

2. Before First Use

A DANGER Risk of suffocation!

- **Keep any packaging materials away from children and pets** these materials are potential source of danger, e.g. Suffocation.
- Check the product for transport damages. Unpack all hardware bags and components to ensure you have all parts before assembly.
- Assemble product on a clean non-marring surface. Remove all the packing materials.

3. Cleaning and Maintenance

- Clean spills immediately by using a soft, clean, lint-free cloth to prevent staining.
- Never use harsh chemicals or solvents on your product as this may damage the product.
- Marks and stains are difficult to remove, we recommend you consult a professional.
 If you use a professional product, pretest it in an inconspicuous area for any signs of discoloration or shrinking.

W2336P251803&04&06

