



# Illustrated Parts for L-3200

## WASTE KING



### Drain Elbow Kit - 1026



### Other Available Accessories



#### Air Switch Remote Controller

- Installs into existing sink hole to operate disposer with plunger air switch.
- Perfect application for island countertops or where electrical switch is unavailable.
- No wiring connections or code restrictions.

#### Air Switch Base Unit

|   |             |
|---|-------------|
| Air Switch Remote Controller                        | ARC-4200    |
| <b>Additional Air Switch Button Finish Options:</b> |             |
| Chrome  | AS-4201-CH  |
| Satin Nickel  | AS-4201-SN  |
| Polished Brass                                      | AS-4201-BR  |
| White   | AS-4201-WH  |
| Almond  | AS-4201-AL  |
| Biscuit   | AS-4201-BIS |

Dishwasher Connector Kit - (connects 1-1/4", 1" and 3/4" outside diameter dishwasher drain hoses to the dishwasher inlet)



**1023**

Unjamming Wrench



**1037**

Disposal purchase comes with all Included Parts,  
Other Available Accessories can be purchased separately

FOR MORE INFORMATION CALL: 1-800-854-3229  
WasteKing.com