



# DJYC2530


ASSEMBLY INTRODUCTION



# Exploded View



# Fitting



**A x 16**  
M6 x 35 mm



**B x 24**  
φ15 x 10 mm



**C x 34**  
φ6 x 30 mm



**D x 24**  
φ4 x 35 mm



**E x 108**  
φ3.5 x 12 mm



**F x 15**



**G x 16**  
φ3 x 16 mm



**H x 2**  
φ6 x 30 mm



**I x 2**  
φ4 x 14 mm



**J x 8**



**K x 1**




**L x 2**  
φ3.5 x 12 mm



**M x 16**



**N x 4**






**O x 8**  
M6 x 40 mm





**P x 4**



# Step 1





# Step 2




### Step 3



### Step 4





## Step 5






B x 8

## Step 6




D x 8




# Step 7






## Step 8





## Step 9





## Step 10




## Step 11






## Step 12




Caution :Need to use the correct part #O instead of part #A.





## Step 13






# Step 14





Caution : If you find it difficult to connect the No. 1 plate to the cabinet, you can loosen part B of the No. 1 plate first, and tighten it after the subsequent installation is completed.




# Step 15



# Step 16



## Step 17





E x 8




N x 4

## Step 18



E x 16

## Step 19





E x 8






P x 4

## Step 20





E x 16

## Step 21





### To adjust the vertical height.

Loosen the four screws "A" on both hinges. Two of them are usually in slotted holes which allows you to adjust up or down by a few mm. Then tighten back up.



### To adjust depth.



Loosen screw "B" and adjust door, if the door can not be adjusted, please loosen screw "C", then try again. Tighten screw "B" and "C".



### To adjust side ways.

Turning the screw "C" on BOTH hinges on each door.

# Step 22



# Step 23

