

**Model Number: PRJG88** 

# MINI PROJECTOR USER MANUAL

### 1.Accessories List

AV signal cable 1pc
Remote control 1pc
Power cord 1pc
User manual 1pc
Warranty Card 1pc

# 2. Important Safeguards

- Please read the manual carefully before operating projector.
   To ensure stable power supply, please use standard power cord.
- II. Please use the power supply and cable indicated on the rating label. The projector should be kept away from cloths, sofas and anything that may block the ventilation scoop. Please keep the unit away from flammable and explosive materials.
- III. Please do not disassemble the unit yourself as this will invalidate the warranty service. To protect your eyes, do not stare directly at the lens when the projector is on. The projector must be kept away from water and any other liquids.
- IV. To prevent electric shock, please keep the projector out of the rain and away from moisture. It is recommended to switch off the projector after it has run for 6 hours non-stop. Please use the original foam and other cushioning materials when transporting the projector.
- V. If the projector does not work, please contact the authorized service agent.

# 3. Specification

Model	Mini projector	Image system	LCD
Native resolution	800*480	Support Max 1920x10	
Lamp	LED	Input voltage	100-240V
Language English, 23 language		Brightness	800lumens
Contrast	1,000:1	Lens	F=140
Image size	36-110 inch	Projection distance	1.19-4.00m
Color	18000K	Projection mode	Front projection
Power waster	38W	Speaker	2.0W*1
Weight	1KG	Size	210*145*80mn
Operation Manual/Remote control		Working temp	-10~38°C
Output	Headphone	Input	HDMI/USB/ VGA/AV


# 4. Multimedia Supported Files

	Task	Format	Video Decode	Audio Decode
	Movie	.avi	MPEG-4	
		.mpg	MPEG-1, MPEG-2	Mp3, AAC
		.dat	MPEG-1	
	Music	.mp3		Mp3
		.m4a/.aac		AAC
	Picture	.jpg/jpeg	Progressive JPEG Baseline JPEG	
		.bmp	ВМР	




The projector does not support Dolby audio decoding.

# 5. Structural Diagram



#### 6.Panel Functions





### 7. Function Operation

- 1.Power 2.Mute
- 3.Backward
- 4.Forward
- 5.Previous
- 6.Next
- 7.Play
- 8.Stop
- 9.Audio Language
- (Only apply for European DVB-T) 10.Record digital TV channel and playback
- (Only apply for European DVB-T)
- 11.Source
- 12.Electronic Menu
- (Only apply for European DVB-T)
- 13. Confirm
- 14.Up/down/left/right(channel+/-/volume-/+)
- 15. Menu
- 16.exit
- 17.numbers

# 8. Function Operation


#### I. Power on/off

Once the projector is plugged in, it will be in Standby mode. Power on: Press the power button on the remote control once to turn the projector on. Power off: Press the power button on the remote control once to turn the projector off.

Place the projector in a certain place within the required distance so that the lens is perpendicular to the screen then rotate the lens until the image is clear.

#### III.Signal Source Selection

Press "SOURCE" key on the remote and press "▲/▼" to find the required source, then press "OK" key to confirm.



#### 9.Menu Setting



Press "MENU" key to enter the main menu, then press "4/>". key to enter each sub-menu.

Press "▲/▼" key to select the sub-menu, then adjust the parameters as per your requirements, and press the "OK" key to confirm.

#### Sub-Menu Functions

I. Picture sub-menu:

Picture Mode Standard, Color Temperature, Aspect Ratio, Noise Reduction, PC Setup, HDMI Mode.

II. Sound sub-menu:

Sound Mode Standard, Balance, Auto Volume, Surround Sound, EQ.

III. Time sub-menu:

Clock, Off Time, On Time, Sleep Timer, Auto Sleep.

IV. Option sub-menu:

OSD Language, Restore Factory Default, OSD Blending, OSD Duration, Flip, Focus.

V. Software update menu

Software update is the firmware updating

Some sub menus are not available 🕌 in some input source.

### 10. Multimedia Player

Insert the U-Disk and select USB from the source menu, the image on the screen will be like below:

Through this interface, you can choose the corresponding "PHOTO", "MUSIC", "MOVIE" or "TEXT" icon to play the required files. For example : choose "MOVIE" by pressing the "OK" key on remote control, then all of video files will be displayed. Please press "OK" key to choose the one you like, the video will be automatically played in a small window and marked red tick "\sqrt", then press III "play"key to get a full screen video.

Remarks: red tick is a selection function, you can select favor video by mark red tick "\sqrt{"}," then the projector will play your favor.



We offer 1 year warranty for the product.