

WHY IS MY HEATER NOT SPARKING?

Be sure you have installed the included battery into the spark ignition module located behind the door on the front of the heater.

IS THE HUNTING BUDDY® CERTIFIED TO RUN OFF OF ANY TANK SIZE LARGER THAN THE 1 LB. CYLINDER?

It is required to only use a 20-lb. tank or smaller with this heater so it remains a portable heater.

MY PILOT FLAME WILL NOT LIGHT:

Be sure you have fuel in your 1 lb. screw-on propane cylinder. When starting the heater after installing a new propane tank, you will need to hold the red start valve down for 30 to 60 seconds to allow the gas supply to reach the pilot tube.

I HAVE HELD DOWN THE CONTROL KNOB FOR MINUTES BUT THE PILOT FLAME STILL WILL NOT LIGHT:

You might need to clean out the pilot tube using a cotton q-tip and rubbing alcohol. Start by pulling half the cotton off each end of the q-tip. Soak the q-tip in the alcohol. Push the q-tip into the pilot tube and be sure to go the full two inches to the bottom. Let it soak for 30 seconds, and then twist as you are removing the cotton swab. You may have to repeat this process a few times before it comes out clean.

