

HOW TO CLEAN AND MAINTAIN YOUR MR. CHAIN PLASTIC PRODUCTS

To keep your Mr. Chain products looking like new, we suggest the following:

1. Any material (sand, gravel, etc.) in the stanchionbase for extra weight should be emptied prior to cleaning.
2. Using a mild soap and a non-abrasive cloth, sponge, or a soft bristle brush for the chain, gently wipe down each part.
3. For oily or greasy dirt and grim, a grease cutting dish soap works well.
4. Rinse thoroughly.
5. Can allow to air dry or use a paper towel to dry all parts.
6. If using something in the stanchion base for added weight, refill the base.
7. Re-assemble all parts and use.

Spot Cleaning:

For spot cleaning or a quick touch-up, use a wet wipe and dry with paper towel.