

# IMPORTANT

Diamond Storage insists on the highest standards of quality in the manufacturing of your products. Each piece has been carefully inspected before shipment. In case of a problem, DO NOT RETURN THE ITEM TO THE STORE

Call Diamond at:

1-800-990-6003

to help with any problem or question you may have.

Thank you.



**MISSING A PART?  
Call our TOLL FREE  
HOTLINE.  
1-800-990-6003**

We appreciate your purchase of the HyLoft storage system. Diamond Storage has made every effort to supply a quality product that insures a lifetime of trouble-free service. In the event that you have any type of problems, please call our toll free number 1-800-990-6003

## **HyLoft Fully Adjustable Ceiling Storage Rack Limited Warranty**

Diamond warrants this product against defects in material or workmanship for the life of the product. Diamond agrees to either repair the product or replace it at the sole discretion of Diamond. This warranty does not include any costs associated with the physical installation, removal or return of the HyLoft storage system.

**This warranty is valid and enforceable provided that the maximum weight supported by each HyLoft Shelf unit does not exceed 250 pounds, evenly distributed. The customer, installer, and/or dealer, releases diamond of all claims, which includes the HyLoft Shelf unit and the structure it is attached to, if the loaded weight exceeds 250 pounds. The unit must also be installed according to the manufacturer's instructions. All fasteners must be checked and tightened at least once annually.**

Only the original purchaser of this product is extended this warranty. No warranty work will be provided under this warranty without purchaser's receipt or other proof of the date of original purchase acceptable to Diamond. This limited warranty covers product failure due to defects in materials or workmanship ONLY! It does not cover corrosion, rust or discoloration of its components, or product failure due to misuse, abuse, faulty installation, alteration, lack of reasonable care, or any other failure not related to defects in materials or workmanship.

There are NO other warranties expressed or implied except those stated here in as required by applicable law.

DIAMOND SHALL NOT BE LIABLE FOR INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. ALL IMPLIED WARRANTIES, IF ANY, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY. Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above exclusion or limitations may not apply to you. No other warranty, written or verbal, will be honored for this product. This warranty gives you specific legal rights and you may also have other rights that vary from state to state.

Diamond is not responsible for damages of merchandise in transit. Repaired or replaced products shall be subject to the terms of this warranty, to be inspected by Diamond prior to return shipment. Damages incurred during transit should be reported at once to the carrier and a claim should be filed with them.

For assistance with your HyLoft storage system or to obtain warranty service call Diamond's toll free number at 1-800-990-6003. Please have the product type and date of purchase when you call to avoid delays. Thank You!

Diamond Storage Concepts  
5130 W. Patrick Lane,  
Las Vegas, NV 89118 | 1-800-990-6003


For more information and frequently asked questions, visit our web site: [www.hyloft.com](http://www.hyloft.com)  
US Patents 7152535; 6435105; 6715427; D416152; D477957; D470353; China Patent 20058000248.8; US and International Patents Pending

©2006

# ASSEMBLY INSTRUCTIONS

## Fully Adjustable Ceiling Storage Rack

Installation Time: 60 minutes or less.












Ceiling Installation Shown-  
See page 5 for alternate  
installation on to  
existing rack

**MISSING A PART?  
Call our TOLL FREE  
HOTLINE.**

**1-800-990-6003**

### Parts Included:

**IMPORTANT-Read through entire instructions before beginning any installation.**

<b>A</b> 4-Downrods 	<b>B</b> 2-Left Side Corner rods 	<b>C</b> 2-Right Side Corner rods 
<b>D</b> 2-Left Side Support Bars 	<b>E</b> 2-Right Side Support Bars 	<b>F</b> 8-Lag Screws 7/16" X 2 1/2" 
<b>G</b> 20-7/16" Hex Bolts 1 1/2" 	<b>H</b> 20-Hex Nuts Serrated 	<b>I</b> HyLoft Sticker 

### Tools Required:





## IMPORTANT-READ THROUGH ENTIRE INSTRUCTIONS BEFORE BEGINNING INSTALLATION

Locate the ceiling joists in the area of desired installation and determine the direction in which they are running. The ceiling mounting plates on Downrods(A) are installed parallel to the ceiling joists. Refer to the diagram below for additional installation clarification.

### 1 INSTALL DOWNRODS

Using Stud/Joist finder locate any 2 Joists at best distance for your storage items

Mount from 27" to 37" apart (from outside edges of ceiling plates)

Ceiling Joist



Place Downrod (A) against ceiling under joist location and mark holes running parallel with the joist. Pre-drill each hole location using a 3/16" drill bit. Install Downrod (A) using 7/16" Socket Wrench or Nut Driver and two (2) 7/16" x 2 1/2" Lag Screws (F).

From the outside edge of the ceiling mounting plate of the Downrod (A) just installed, measure from 27" to 37" (depending on size of storage area desired) inches along ceiling joist and mark this location. This mark will be the **OUTSIDE** edge of the second ceiling mounting plate of second Downrod (A). Install second Downrod (A) and make sure it lines up with the first Downrod (A) installed on the joist.

Repeat to install the remaining two (2) Downrods on a joist which can vary from any distance apart from the 1st joist (depending on size of items to be stored).

**IMPORTANT:** Downrods must be mounted perfectly in line and square to each other.

### 2 INSTALL CORNER RODS & SUPPORT BARS




Assemble (2) Corner Rods (B & C) to each of the Support Bars (D & E) by sliding one inside the other as shown. Determine the length down from the ceiling you want the unit to hang (from 17" to 26").

Attach the Corner Rod and Support Arm assembly to Downrods (A) at the predetermined length using two (2) 7/16" x 1 1/2" Hex Bolts (G) and two (2) serrated Hex Nuts (H) for each connection to all Downrods (A) using a 7/16" wrench or nut driver. Adjust width & fasten Support Bars (D & E) to each other and to Corner Rods (B & C) with two (2) serrated Hex Nuts (H) at each connection.

Place the Hyloft Sticker provided on Corner Rod (A) for easy access to contact information.

Make sure that all nuts, bolts and screws are tight. Do not load with more than 250 lbs, evenly distributed.

## Alternate Installation on to Existing Hyloft Unit



Determine location needed for storage & insert Downrods (A) through grid of existing Hyloft Rack at an angle. Straighten and pull down Downrods (A) until the top of the Downrod hooks over the grid wires as shown. Continue with step 2 on previous page to install Corner Rods (B&C) and support Bars (D&E), adjusting height and width as needed.

**IMPORTANT:** Combined storage weight of both racks must not exceed 250 lbs.