- Ensure that your hands are dry when operating the controls or removing the plug.
- 9. Do not use while bathing or showering. Use only in a dry area.
- Always unplug the unit from the electrical outlet immediately after using and before cleaning.
- 11. Keep out of reach of children.

OPERATION

- 1. Make sure foot bath is in OFF position.
- Place foot bath on floor, fill with warm or cold water to the level indicator "MAX". Do not fill above water-level indicator. Never overfill. Plug into wall outlet. Never plug in or unplug the foot bath while your feet are in water.
- The heat setting is designed to maintain the temperature of warm water, not to heat water.
- Sit in a chair and place your feet in the water. Never stand in foot bath.
- 5. Push button to start.
- Push button to OFF position after use and disconnect from outlet before emptying water. Empty water out of the side opposite side with control knobs.
- Pour water out of the footbath from the side opposite the line cord only.
- 8. To clean foot bath, turn appliance off and unplug from outlet and then rinse with water. (Never submerge unit in water.) Wipe with a damp cloth. Do not use any strong chemical cleaners or solvents such as benzene, harsh detergents or abrasives.
- 9. This unit has no user-serviceable parts.
- 10. To store: Unplug the appliance from the outlet. Store in appliance box or a clean, dry place. To avoid breakage, do not wrap the power cord around the unit. Do not hang the unit by the cord.

MASSAGING FOOT SPA WITH HEAT FEATURES

- 1 Push button control turns on/off bubbles & heat
- 2 Over 150 stimulating massage nodes
- 3 Line cord wrap
- 4 Footrest splashguard
- 5 Massaging attachment



LIMITED ONE YEAR WARRANTY

Conair will repair or replace (at our option) your unit free of charge for 12 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service center listed below, together with your purchase receipt and \$12.00 for postage and handling. California residents need only provide proof of purchase and should call 1-800-366-0937 for shipping instructions. In the absence of a purchase receipt, the warranty period shall be 12 months from the date of manufacture.

ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 12-MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER. Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

For information on any Conair® product call: 1-800-326-6247 or 1-800-528-9384, or visit us on the web at: www.conair.com.


Please register this product at: www.conair.com/registration

Service Center

10PS117005

Conair Corporation Service Department 7475 N. Glen Harbor Blvd. Glendale, AZ 85307 © 2010 Conair Corporation www.conair.com

IB-10364



Model FB5X

INSTRUCTIONS **DNITARES**



the proper outlet. Do not change the plug in anyway. the plug. It it still does not fit, contact a qualified electrician to install outlet only one way. It the plug does not fit fully in the outlet, reverse plug (one blade is wider than the other). This plug will fit in a polarized To reduce the risk of electric shock, this appliance has a polarized

CAUTIONS

- 2. Do not use if you experience unexplained pain or swollen muscles, cancer, infection, fracture or persistent pain. condition, including but not limited to pacemaker use, pregnancy, 1. Consult your physician before using in case of illness or medical
- 3. Do not use it you have any of the following conditions: or following a serious injury, before consulting your physician.
- 4. This product should not be used by any individual suffering purned, broken, swollen or inflamed skin. sores, varicose veins, poor circulation or bruised, discolored, or thrombosis, hemorrhages, open or fresh wounds, ulcerated diabetes, tuberculosis, benign or malignant tumors, phlebitis
- could be a symptom of a more serious condition. time, discontinue use and consult your physician. Persistent pain b. If you experience pain in a muscle or joint for a prolonged period of capacity to teel or have sensation in any part of the body.

trom a condition that limits or altogether inhibits the user's

or discomfort result, discontinue use and consult your physician. 6. Use of this product should be pleasant and comfortable. Should pain

V. Never use while sleeping or drowsy.

INSTRUCTIONS **SAYE THESE**

Servicing of Double-Insulated Products

ou rue broauct. INSULATED." The symbol (square within a square) may also be marked is marked with the words "DOUBLE INSULATION" or "DOUBLE must be identical to the parts they replace. A double-insulated product service personnel. Replacement parts for a double-insulated product and knowledge of the system, and should be done only by qualified product. Servicing a double-insulated product requires extreme care insulated product, nor should a means for grounding be added to the instead of grounding. No grounding means is provided on a double-In a double-insulated product, two systems of insulation are provided



MASSAGER INSTRUCTIONS

Place foot on massager. Move your foot around for more pressure and

RECOMMENDED MASSAGING TIMES

regarding treatment, we recommend you consult your physician. to suit your needs and personal comfort. If you have any concerns pis or her response to massage. You should adjust your massage time to cool before using again. As a person's metabolism varies, so does Treatment may be applied once or twice daily as desired. Allow unit Generally, massage should not last longer than 10–15 minutes.

- 6. Do not carry this appliance by supply cord or use cord as a handle.
- Y. Keep the cord away from heated surfaces.
- 8. Never operate the appliance with the air openings blocked. Keep the
- 9. Never drop or insert any object into any opening. air openings free of lint, hair and other particles.
- 10. To disconnect, turn all controls to the OFF position, then remove plug
- from the outlet.
- Do not use outdoors.
- where oxygen is being administered. 12. Do not operate where aerosol (spray) products are being used or
- 13. Do not attempt to plug in or unplug unit while feet are in the water.
- in bath and remove feet from bath while in a seated position only. 14. Do not stand on or in the foot bath. Use only while seated. Place feet
- obeuiuds way be biocked. 15. Never operate on a soft surface, such as a bed or couch, where air
- pe aangerous. nustiended use of neat by children or incapacitated persons may use on sensitive skin or in the presence of poor circulation. The 16. Use heated surface carefully; may cause serious burns. Do not
- This appliance is for household use only.
- toot bath. 18. To prevent scalding, never add boiling or steaming water to the

INSTRUCTIONS YT34AS TNATROYMI

:gniwoliot precautions should always be followed, including the When using an electrical product, basic safety

Before Using This Appliance. READ ALL INSTRUCTIONS

1. Always unplug this appliance from the electrical outlet $\mathsf{DANGER}_{\mathsf{T}}$ — To reduce the risk of death by electric shock:

- 2. Do not reach for an appliance that has fallen into water. Unplug immediately after using and before cleaning.
- 3. Do not use while bathing or in a shower.

injury to persons:

or sink. Do not place or drop into water or other liquids. 4. Do not place or store appliance where it can tall or be pulled into a tub

WARNING — To reduce the risk of burns, electrocution, fire or

- taking off parts. Unplug from outlet when not in use, and before putting on or 1. An appliance should never be left unattended when plugged in.
- occur and cause fire, electric shock, or injury to persons. 2. Do not operate under blanket or pillow. Excessive heating can
- bersons with certain disabilities. 3. This appliance should not be used by, on, or near children, or
- manual. Do not use attachments that were not intended for this 4. Use this appliance only for its intended use as described in this
- purchase for examination and repair. or dropped into water. Keturn the appliance to the place of it is not working properly, or it it has been dropped or damaged, 5. Never operate this appliance if it has a damaged cord or plug, if