

Important Installation Reminder: If existing PTAC outdoor grill/louvers already have baffles installed, then please remove baffles from Distinctions PTAC unit by removing 2 screws on each side before sliding the new PTAC into the wall sleeve. Please refer to page number # 2 on how to inspect the baffles from inside the room.



Outdoor Grill/Louvers with Baffles

Please remove baffles from PTAC unit when installing with these type of grill/louvers.

Remove Baffles from PTAC



Remove Baffles from PTAC



Remove Baffles from PTAC

