


Assembly Instructions



Please look in the under Seat Panel for hardware packs

CAUTION: You must read this before you proceed.

BENCH



CAUTION : This Bench is NOT a TOY.
Keep your child / children at bay in the process of assembly.
For turning the Bench and to prevent damage to the Bench, 02 persons may be needed to execute this action.


No.	Picture	Description	Qty
A		Seat Panel	1
B		Leg	4

Hardware

No.	Picture	Description	Qty
①		Bolt (M8x20mm)	13
②		Flat Washer (M8.5/18x2mm)	13
③		Allen Wrench (M4)	2

Assembly Preparation

Before Beginning Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Steps

OVERVIEW




This Bench has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Bench parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1




Unpack and place all parts on a clean, non-marring surface.

Step 2



With the assistance of your adult partner, lay the Seat Panel (A) facedown onto a clean, flat surface to avoid any scratches or damage to the product.

Step 3




Attach Leg (B) into the Seat Panel (A), using bolt (①), Flat Washers (②) and Allen Wrench (③) as above picture.

Repeat the same process with the other 3 Legs (B)

Do not fully tighten the Bolts.

Step 4



With assistance from your partners, turn the Bench back to normal flat ground
EXERT pressure, floorwards, onto the Bench

This pressure will help the Legs and Seat panel reach alignment at all joints.
Check for wobbles.

In a sequential manner, gradually tighten all Bolts until evenly secured. Inspect
the Bench and make sure all parts are adequately connected.

Your Bench is ready for use.

This Bench can only be used on a flat, level surface.

Care & Maintenance

- ⊘  ● Prolonged exposure to rain may cause rusting which can stain floors.
- ⊘  ● Do not put hot items directly on furniture surface.
- ⊘  ● Do not clean furniture with harsh cleansers or polish.
- ✓  ● To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
- ⊘  ● Children should not climb or jump on the furniture.
- ⊘  ● Do not write on furniture without a padded barrier to protect the surface.
- ✓  ● To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
- ⊘  ● Not for commercial use. For residential use only.
- ⊘  ● Stains may be removed with mild soap solution and damp cloth.
- ✓  ● Dust and pick-up spills using a clean, non-colored, lint-free cloth.