

ASSEMBLY INSTRUCTION 30INCH BATH VANTINY (COMBO) SKU: N759P225994



Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.

Compare with the parts list to be sure all parts are present.

"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"



IMPORTANT:

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

PLEASE DO NOT RETURN TO STORE



Please do not return this product to the retailer!! We are able to assist you in ANY way

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.

- 1. Note: This is not a clothing storage cabinet and it is not recommended to use it as a clothing storage cabinet.
- 2. All cabinets come with TRD, stainless steel or our "L-Bracket "when shipped.


Before Installation


Important – Please read these instructions fully before starting assembly

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.


- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

Cam Lock Assembly Instructions






Part List 2 1 Top Side Panel (R) - 1pc Front Top Bar - 1pc 3 4 Top Side Panel (L) - 1pc Mid Panel - 1pc 5 6 Top Panel Rear - 1pc Bottom Panel Rear - 1pc 7 8 Crossbar Front - 1pc Mid Panel - 1pc 10 9 Bottom Side Panel (R) - 1pc Bottm Side Panel (L) - 1pc 11 12 Bottom Frame - 1pc Cabinet Feet - 4pcs 13 14 Door - 1pc Round Bar - 2pcs





Part List





Hardware List


	Б	
_ A _	B	<u>C</u>
ø6x35mm	ø14.5x12mm	ø8xø4x32mm
Three in one bolts - 48pcs	Three in one lock - 48pcs	Round head screw - 16pcs
D	E	F
€)	(a)—2000000000000000000000000000000000000	
ø8xø4x25mm	ø13x1/4"x40mm	ø1/4"x16x1mm
Round head screw - 2pcs	Hex-Head bolts - 4pcs	Washer - 4pcs
G	Н	
	%	
4mm	ø24x24mm	ø5/32"x19mm
Allen key - 1pc	Handle - 5pcs	Handle screw - 3pcs
J	K	L
		(†)20000000>
ø5/32"x32mm		ø7xø3.5x15mm
Handle screw - 2pcs	Damping hinge - 2pcs	Flat head screw - 12pcs
M	N /	
Y////)		
ø8x30mm	66	
Wood dowel - 44pcs	Anti fall hardware (1set)	





































STEP: 20






STEP: 21




STEP: 22






HINGE ADJUSTMENTS



1 Sideways / Tilt adjustment


Turn the screw clockwise to move the door further away from the side of the cabinet anticlockwise to move the door closer to the side of the cabinet



2 4 Height adjustment

While supporting the weight of the door, turn the screws

clockwise to move the door up anticlockwise to move the door down



3 Forward and back adjustment

If the gap between the back of the door and the cabinet is too small, and the door may not close fully. Turn the screw

clockwise to decrease the gap between the door and the cabinet

anticlockwise to increase the gap between the door and the cabinet

