

Care and Maintenance Manual

Before using this product, please wipe up the wicker/rattan with a clean, wet cloth/towel.



Although the outdoor furniture has the function of UV protection, it will also cause some damage if exposed to the sun for a long time. To better extend the service life of the product, the following suggestions are given to you:

1. Regularly shade and protect from the sun, and avoid long-term exposure outdoors. Where possible, place under patio, awnings. Cover the furniture when not in use to protect it from rain, dust, and UV rays.
2. Do some cleaning work regularly and wipe with warm water. Do not use bleach or other solvents. We do not recommend frequent washing or machine washing cushion covers because it will damage the cover's UV protection coating.
3. Please keep cushions inside for rainy days and quickly dry the cover surface once it drops some water/liquid on it. This will help prevent mildew by removing dirt particles that may accumulate.
4. Turn the mat over and use + rotate the position to wear it evenly and avoid premature aging due to long-term exposure to the sun on one side.
5. During the winter or extended periods of non-use, store the furniture indoors in a dry, well-ventilated space to prevent mold and material degradation.

NOTE:

- 1) The back cushion is vacuumed sealed. After opening the bag, some time and fluffing will be required for recovering the back cushion's original thickness.
- 2) Rub and flap the cushion to return to original thickness before using.
- 3) Wrinkle on fabric caused by special package will disappear after some time using. It suggests to use no wrinkle side facing forward.

**** REMOVE CUSHION FROM PLASTIC BAG. FLUFF AND RUB THE CUSHIONS AS SHOWN TO RETURN CUSHION TO ORIGINAL SHAPE AND THICKNESS.**



NOTE: DO NOT USE A KNIFE OR SCISSORS TO OPEN THE PLASTIC BAG AS IT WILL DAMAGE THE CUSHION.

(Use fingers to pull plastic bag apart)

