


OWNER'S MANUAL

47" WOOD BUFFET SIDEBOARD



Contact Us

If you have any questions,
Please contact customer service.

service@cozfurn.com

Scan the QR code to watch the installation video.



SAFETY PRECAUTIONS

Before You Start

- ★ Please take the time to carefully read through the whole of these instructions before you commence.
- ★ Unpack, inspect and check off all of the contents. If there are any defective or missing parts after unpacking, please cease assembly and get in contact with us immediately.
- ★ Separate and count all your parts and hardware.
- ★ Have the following tools: Flat Head Screwdriver, #2 Phillips Head Screwdriver and Hammer



WARNING

- ★ Do not stand or sit on the product.
- ★ Children and pets should be kept from your assembly area if possible. Supervise children and pets if they are in the assembly area.
- ★ Never touch with sharp objects or corrosive chemicals, which may damage the surface of the item.
- ★ Do not expose product to direct sunlight or rain; and do not put it in a humid place.



CAUTION

- ★ This item is heavy. Please handle with care. Two or more people are required for this assembly.
- ★ It would be sensible to lay a sheet or blanket on the floor where you intend to work to avoid scratching this product and to protect your floor.
- ★ Assemble the product as close to its intended final position in the room as possible.
- ★ There may be some odour after unpacking the parcel, please put this item in a ventilated place for a few days and the odour will dissipate.
- ★ If using a power drill or power screwdriver for screwing, please be aware of to slow down and stop when screw is tight.
- ★ Failure to do so may result in stripping the screw.

PRODUCT WARRANTY INSTRUCTION



Free Warranty Period:

The free warranty period starts from the product receipt date and lasts one year.



Coverage during the Free Warranty Period:

1. If any components of the purchased product are damaged due to non-human-induced reasons (natural wear and tear excluded), corresponding new parts will be replaced free of charge.

2. If the entire purchased product is damaged due to non-human-induced reasons (natural wear and tear excluded) and cannot be further used, corresponding parts or a brand-new product will be replaced free of charge.



Coverage after the Free Warranty Period:

After the warranty period expires, replacement components will be provided to customers at cost price for continued service.



Additional Services:


After purchasing the product, customers can consult our staff for any product-related inquiries.




Contact Email :

service@cozfurn.com



ACCESSORIES DISPLAY





									
①*8	②*8	③*16	④*8	⑤*20	⑥*1	⑦*3	⑧*3	⑨*36	⑩*12
									
⑪*2	⑫*4	⑬*2	⑭*2	⑮*1	⑯*2	⑰*4	⑱*2	⑲*12	⑳*12

PRODUCT ASSEMBLY

STEP 1




STEP 2





Email: service@cozfurn.com

PRODUCT ASSEMBLY

STEP 3




STEP 4




Email: service@cozfurn.com

PRODUCT ASSEMBLY

STEP 5




STEP 6








Email: service@cozfurn.com

PRODUCT ASSEMBLY

STEP 7





STEP 8





Email: service@cozfurn.com

PRODUCT ASSEMBLY

STEP 9




STEP 10



Email: service@cozfurn.com


PRODUCT ASSEMBLY

STEP 11



You can adjust the height of your feet by turning the foot screws

STEP 12



Email: service@cozfurn.com