





















YZ483

PART LIST			HARDWARE LIST		
No	DESCRIPTION	QTY	No	DESCRIPTION	QTY
1	 Seat Frame	1PC	A	 BLOT 1/4" X 50mm	12PCS
2	 Left ARM	1PC	B	 BLOT 1/4" X 38mm	3PCS
3	 Right ARM	1PC	C	 BLOT 1/4" X 18mm	4PCS
4	 Seat Cushion	2PCS	D	 LOCK WASHER M4	19PCS
5	 Backrest	1PC	E	 FLAT WASHER M4	19PCS
6	 Front Panel	1PC	F	 ALLEN WRENCH M4	1PC
7	 Back Cushion	1PC	G	 Plastic	4PCS
8	 Drawer	2PCS	H	 Wheel	4PCS
9	 Pillow	2PCS	I	 Leg	4PCS


STEP 1




STEP 2




STEP 3






You can pull the buckle out by following the direction indicated by the arrow




This is the only direction that can be locked.




Place round iron tube as shown for better drawer assembly

STEP 4



X 2


STEP 5




X 2

STEP 6


The wheels are buckled on an iron mesh.




STEP 7






STEP 8




STEP 9



STEP 10



STEP 11



STEP 12

