


OPERATION INSTRUCTIONS ROTATION SET

N719P234190







1

HEALTH CAUTION

- ☑ Individuals with pacemakers should not use this product.
- ☑ If you have pain in a muscle or joint after using for a prolonged period of time, discontinue using and consult your doctor. Persist pain could be a symptom of a more serious condition.

MAINTAINANCE INSTRUCTIONS


TO STORE:

Place unit in its box or safety dry and cool place. Avoid putting chair in contact with sharp edges or pointed objects which might cut or puncture the fabric. Do not wrap attached power cord around the unit. Do not pull the unit by power cord.

TO CLEAN:

- ☑ Do not use any liquid to clean. Clean fabric cover by wiping with a
 damp sponge, using a mild detergent or suds. Pat with clean, dry
 cloth.
- ☑ Do not use any abrasive cleaners, brushes, gasoline, kerosene, glass furniture polish, paint thinner or water hotter than 120° F to clean the unit.

ASSEMBLY INTRUCTIONS




GENERAL ASSEMBLY INFORMATION GUIDE


Please read the following instructions prior to assembling this product:


- 1. To avoid damage, assemble this product on a non-abrasive surface such as carpet.
- 2. Make sure all bolts are tightly fastened before use.
- 3. For home use or light commercial use only.
- 4. Please make sure you have all parts before assembly.


PARTS LIST





HARDWARE














WARNINGS

- ⊠ Sit down in the chair gently. To avoid tipping over, do not throw yourself into the chair. Move the chair into the reclining position slowly, making sure that no children or pets are in close proximity. Do not allow children to play on or around the chair, particularly when it is in an open position.
- ☑ Close the recliner completely before getting out of it.
- ⊠ Never sit on the footrest when it is open, even if it is a child.
- □ To eliminate the risk of tipping over, do not sit on the arms or footrest
 of the chair.
- minstyle min
- Maximum weight capacity is 330LBS, do not allow any person who
 over 330LBS to sit on the recliner.
- ☑ Please forbid people with the following ailments from using this sofa:
 Those people with severe symptoms of heart disease, high blood
 pressure, cerebral thrombosis and others who are sensitive to heat or
 completely insensitive to heat, those with brittle bones or have issues
 with waist support pregnant women, children and others where it has
 been determined they are not suitable to use this product under the

guidance of doctors.

- ☑ To fully recline the sofa, ensure the sofa well, you need to put the sofa
 at least 100cm away from the wall or any other obstacle.
- □ Product cannot touch water, fire, etc. Product can also not come in contact with sharp objects (knives, nails, etc.)

MAINTENANCE MANUAL INSTRUCTIONS

- ☑ To avoid dropping, you should carry the sofa carefully.
- ☑ If you find dirt and or stains on the chair, spray the sofa with a sofa specific cleaner then use a sponge or cloth to wipe the dirt away. Do not use water, soapy water or cleaner with waxed woode n areas. Take care to wipe the sofa carefully and gently.
- ☑ Do not put the sofa in an area with direct sunlight and do not put the sofa directly in front of an air conditioner, this will fade the upholstery and make it brittle.