

ASSEMBLY INSTRUCTIONS

ITEM NO. FB3010CST-GY-T-3559+BE FB3010CST-WA-T-3559+BE




ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



PARTS LIST				
NO.	DIAGRAM	PART NAME	Q'Ty	
1		TABLE TOP	1PC	
2	€	LEG	4PCS	


HARDWARE LIST				
NO.	DIAGRAM	PART NAME	Q'Ty	
Α		BOLT / BOULON	8PCS	
		Ø5/16" x2-3/8"		
В		LOCK WASHER	8PCS	
		Ø5/16"1/16	01 00	
С		FLAT WASHER	8PCS	
		Ø5/16"x 19mm	0763	
D		ALLEN KEY	1PC	
		1/6" x 2-1/4"		



Exploded View

PARTS LIST			
NO.	DIAGRAM	PART NAME	Q'Ty
1		SEAT FRAME	1PC
2		CUSHION	1PC
3	3	LEG	4PCS


HARDWARE LIST				
NO.	DIAGRAM	PART NAME	Q'Ty	
Α		BOLT / BOULON	8PCS	
		Ø1/4" x2-3/8"	0.00	
В		LOCK WASHER	8PCS	
		Ø1/4"1/16		
С		FLAT WASHER	8PCS	
		Ø1/4"x 19mm		
D		ALLEN KEY	1PC	
		1/6" x 2-1/4"		
E	(S)	SCREW #3x15mm	8PCS	





ASSEMBLY INSTRUCTIONS

ITEM NO. FB3052CST-SC-4PK



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

PARTS LIST			
NO.	DIAGRAM	PART NAME	Q'Ty
1		CHAIR BACK	1PC
2		WOODEN SEAT	1PC
3		LEG	2PCS

HARDWARE LIST				
NO.	DIAGRAM	PART NAME	Q'Ty	
Α		BOLT / BOULON Ø1/4" x 1-1/2"	2PCS	
В		BOLT / BOULON Ø1/4" x 2-3/8"	4PCS	
С		BOLT / BOULON Ø1/4" x 3"	4PCS	
D		LOCK WASHER Ø1/4"	10PCS	
Е		FLAT WASHER Ø1/4" x 19mm	10PCS	
F		ALLEN KEY 4mm	1PC	

