




Ax1




Bx1




1



2



3



Push
Drücken
Pousser
Presione
Spingere
Wciśnij

4

