


COFFEE TABLE

Assembly Instructions - Please keep for future reference

N735P502391K-N735P502391B



Dimensions

Width - 47.24inch

Depth - 23.62inch

Height - 18.11inch

Important - Please read these instructions fully before starting assembly



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit of your floor.

- Parts of the assembly will be easier with 2 people.



TO reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.

- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly only once the product is complete should you fully tighten the bolts.

Regularly check and ensure that all bolts and fittings are tightened properly

WARNING

**In order to help prevent overturning-
please follow these instructions**

To help prevent product toppling over please follow the below steps:-

Use the anti tip strap or wall fixing method provided (if applicable)

Do not allow children to climb or hang on the furniture

Do not open more than one drawer at a time

Do not place heavy items in the top drawers

Do not place heavy items on top of the furniture, unless the furniture has been

designed for this purpose

WARNING: Risk of Shatter Associated with Glass Furniture

Please note that in rare instances, glass furniture that is damaged by chips or scratches may break. seemingly of its own accord. Damage to the glass(not always visible)can get worse over time until it reaches a critical point when it may shatter. In the event of damage, this product is designed to shatter into lots of small granular pieces rather than large shards. This is a safety feature to reduce the risk of injury.


To reduce the risk of damage, we recommend the following:

- **During assembly do not lay the glass directly onto hard or rough surfaces. Lay the glass on a blanket or cardboard.**
- **When lifting or moving the product, ask for someone to lend a hand. Trying to move a product on your own can lead to accidents.**
- **Do not use the furniture if any parts are missing or broken.**
- **Do not place very hot or very cold items directly on the glass surface; we recommend using a trivet. Extreme temperature differences over small areas can cause damage,which could in turn lead to shattering.**
- **Do not sit or stand on the glass surface.**
- **Do not strike the glass with hard or pointed items, or use the glass as a chopping surface.**
- **Do not drag rough or heavy objects over the top of the glass.**

Components - Fittings

Please check you have all the panels listed below



Noease check quantitie below are the correcet amount to complete the assembly.In aome cases more fittings may be supplied than are required

		
M6×12mm	Φ20*Φ5.2mm	M4
A×24PCS	B×12PCS	C×1PC


Tools required



Hexagon wrench


			
①×2PCS	②×2PCS	③×2PCS	④×4PCS

Assembly Instructions




Assembly Instructions

Step 1




A  16PCS

Step 2



A  8PCS

Step 3



B  12PCS

Step 4

