







7. Water test and leak detection

- 1. After connecting all pipes, please dis-assembling the plastic protection cover, and switch on/off the cartridge, check all connections without any leakage, and all connections connecting to the required functional outlets.
- 2. Re-install the plastic protection cover to the valve.



8、Wall tiling program

- 1.Use a parallel ruler to make sure the wall and valve being parallel.
- 2.Use a knife to cut the rest of plastic edge above the tiles.











detergent.

3.Do not use any scrubbing detergent, polisher, sand -cloth, paper tissue or scraper.

or soap.

1.Users under age 14 must be accompanied by an adult otherwise young users may be scalded by hot water.

water.

7

9, Cover and handle installation

1. Take off the plastic protection cover.

2.Put the cover board on the valve and tight the handle firmly.

8

12、Cleaning & Maintenance

To keep the product clean& shining, follow the steps as follows:

1.Flush with clean water & dry with soft cloth only;

2.If any dirt, clean with soft liquid or transparent glass

4. Do not use acid detergent, insoluble & grain-like detergent

13、Important notice

2.All users need to be careful when you turn cold water to hot