



31" Desk • PDS3116 • INSTRUCTIONS

Organize your parts and hardware. You may need a rubber mallet.



MUST FOLLOW STEPS IN ORDER OR FURNITURE MAY BE DAMAGED



IMPORTANT NOTICE:

Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched. Check to be sure that you have all parts.

Remove all wrapping materials, including staples & packing straps before you start to assemble.

Keep all hardware parts out of reach of children.

RCGENCY



