


Assembly Instructions

Caution : You must read this before you proceed




Please look in the Seat Panel for hardware packs

BENCH




CAUTION : This Bench is NOT a TOY. Keep your child / children at bay in the process of assembly. For turning the Bench and to prevent possible damage to it, 02 persons may be needed to execute this action

Parts List


Label	Picture	Description	QTY
A		Leg Panel	2
B		Seat Panel	1
C		Support Bar	1

Hardware

No.	Picture	Description	Qty
①		Bolts (M6x40mm)	3
②		Screw (M6x60mm)	3
③		Bolt (M6x90mm)	5
④		Washer (6.5/20 x 2mm)	7
⑤		Allen Key 4 (30 x 80mm)	2

Assembly Preparation

Before Beginning Assembly:



1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66

67

68

69

70

71

72

73

74

75

76

77

78

79

80

81

82

83

84

85

86

87

88

89

90

91

92

93

94

95

96

97

98

99

100

101

102

103

104

105

106

107

108

109

110

111

112

113

114

115

116

117

118

119

120

121

122

123

124

125

126

127

128

129

130

131

132

133

134

135

136

137

138

139

140

141

142

143

144

145

146

147

148

149

150

151

152

153

154

155

156

157

158

159

160

161

162

163

164

165

166

167

168

169

170

171

172

173

174

175

176

177

178

179

180

181

182

183

184

185

186

187

188

189

190

191

192

193

194

195

196

197

198

199

200

201

202

203

204

205

206

207

208

209

210

211

212

213

214

215

216

217

218

219

220

221

222

223

224

225

226

227

228

229

230

231

232

233

234

235

236

237

238

239

240

241

242

243

244

245

246

247

248

249

250

251

252

253

254

255

256

257

258

259

260

261

262

263

264

265

266

267

268

269

270

271

272

273

274

275

276

277

278

279

280

281

282

283

284

285

286

287

288

289

290

291

292

293

294

295

296

297

298

299

300

301

302

303

304

305

306

307

308

309

310

311

312

313

314

315

316

317

318

319

320

321

322

323

324

325

326

327

328

329

330

331

332

333

334

335

336

337

338

339

340

341

342

343

344

345

346

347

348

349


350

351


352

35


Step 2



2.1



2.2




Place the Seat Panel (B) with the inside facing upwards onto a clean, soft surface to avoid any scratches or damage to the product.

2.1: Align the Leg Panel (A) into the positions in the Seat Panel (B), as shown above.

2.2: Secure the Leg Panel (A) to the Seat Panel (B) with Bolts (3), Washers (4) and the Allen Key (5), then with Bolts (1) and Washers (4), also using the Allen Key (5).

Do not fully tighten the Bolts

Step 3




Affix the Support Bar (C) to the Leg Panels (A) using Screws (2) and the Allen Key (5).

You may need to push the Leg Panels (A) slightly outwards to affix the Support Bar (C)

Only loosely tighten the Screws.

Step 4




Repeat the same process to attach the remaining Leg Panel (A) to the Seat Panel (B) and Support Bar (C)

4.1: Align the Leg Panel (A) into the positions in the Seat Panel (B) and Support Bar (C), as shown above.

4.2.1: Secure the Leg Panel (A) to the Seat Panel (B) with Washers (4), Bolts (3), and the Allen Key (5), then with Washers (4) and Bolts (1), also using the Allen Key (5) to secure them in.

4.2.2: Affix the Support Bar (C) to the Leg Panels (A) using Screws (2) and Allen Key (5). **Do not fully tighten the Bolts and Screws**

Step 5



Turn the Bench right side up.

Inspect the Bench and make sure all parts are adequately connected.

In a sequential manner, tighten all Screws and Bolts at all joints.

With assistance from your adult partner, adjust the Levelers to the desired height to avoid wobbles.

The Bench is ready to be used.

CAUTION : When tightening these screws and bolts, tighten sequentially.

DO NOT tighten any screw or bolt fully and then move towards the next one. This could cause the frame to warp.

WARNING!! IF THE BENCH IS NOT STABLE , IT COULD LEAD TO DAMAGING THE PRODUCT.

Care & Maintenance

- 🚫  • Do not put hot items directly on furniture surface
- 🚫  • Do not clean furniture with harsh cleansers or polish.
- ✓  • To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
- 🚫  • Children should not climb or jump on the furniture.
- 🚫  • Do not write on furniture without a padded barrier to protect the surface.
- ✓  • To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
- 🚫  • Not for commercial use. For residential use only .
- 🚫  • Stains may be removed with mild soap solution and damp cloth.
- ✓  • Keep away from sources of ignition.

- ✓  • Dust and pick-up spills using a clean, non-colored, lint-free cloth.