



AIR PURIFIER

USER MANUAL

WWW.KOIOSSHOP.COM

CUSTOMER SERVICE

Our customer service team is standing by to assist you if you have any questions or concerns.



www.koiosshop.com



support@koiosshop.com



1-855-888-2111




m.me/KoiosShop

CONTENT

DESCRIPTION	01
SAFETY PRECAUTIONS	03
IMPORTANT MATTERS	05
WORKING PRINCIPLE	06
BEFORE USE	07
INSTRUCTIONS FOR USE	09
MAINTENANCE	11
STORE	14
COMMON MALFUNCTIONS	15


1 DESCRIPTION



PRODUCT DESCRIPTION

- | | | | |
|---|--------------|---|------------------------------------|
| A | Air outlet | B | Timer / wind speed indicator light |
| C | Power button | D | Air inlet |
| E | The handle | F | Type-c interface |
| G | Caseback | | |

DESCRIPTION 2



PRODUCT DESCRIPTION

- ① Timer indicator
- ② Wind speed indicator
- ③ Power indicator light / Filter reset indicator
- ④ Power button

3 SAFETY PRECAUTIONS

Please read this manual carefully before using the product, and keep this manual in a safe place.

You need to read these instructions carefully and follow these suggestions:

- ◆ For your safety, this product complies with applicable standards and regulations (low voltage, electromagnetic compatibility, environmental protection ...);
- ◆ This product is not suitable for persons with physical, sensory, or mental disorders (including children), or those who lack experience or relevant knowledge, unless Supervised by someone responsible for their safety, or given prior guidance on the use of the machine;
- ◆ Children should be supervised to ensure that they do not play with the product;
- ◆ This product is not intended for use by children under the age of eight, persons without relevant experience and knowledge, or persons with physical, sensory, or mental disabilities, except they must be trained or instructed on how to use this product safely and know the dangers involved with this product;

SAFETY PRECAUTIONS 4

- ◆ If the power cord is damaged, please do not use this product. If the power cord is damaged, it must be repaired by the service department of manufacturer, or replaced by the specialized personnel in similar departments;
- ◆ Children must not clean and maintain the product without supervision;
- ◆ When performing maintenance on this product, refer to the "Maintenance" section in the manual;
- ◆ Keep the power cord out of reach of children under eight years of age;
- ◆ This product is designed for indoor use and should not be used in industrial applications;
- ◆ If the product is damaged due to improper operation, the warranty card is invalid;
- ◆ Do not operate the product in dusty, humid or fire-hazardous areas;
- ◆ Before use, always ensure that the electrical plug and power cord are good;
- ◆ Do not insert foreign objects (such as needles) into the device;
- ◆ Do not pull on the power cord or device, or even unplug the plug from the outlet;
- ◆ Before use, extend the length of the power cord to a suitable length.

5 IMPORTANT MATTERS

- ◆ Do not cover the air inlet or outlet.
- ◆ Do not touch the appliance with wet hands.
- ◆ Do not allow any liquid to enter the product.
- ◆ Do not use this product in a humid place.
- ◆ Do not place this product near a heat source.
- ◆ Do not place anything or insert foreign objects on this product.
- ◆ Please do not place this product near flammable items or products (such as curtains, aerosols, organic solvents, etc.)
- ◆ Place the product on a stable surface and do not use it on its own or tilted;
- ◆ When not using the product for a long time: Use the button (5) to turn off the device and unplug the power plug.
- ◆ Turn off the device and unplug it before moving it.
- ◆ Remove the plug when assembling or cleaning the device.

WORKING PRINCIPLE 6

Activated carbon and HEPA composite filter





DIAGRAM OF PURIFICATION



7 BEFORE USE


Select the room where the air needs to be purified, and place the purifier on a stable floor or table in the room.

Please confirm that the filter bag inside the machine has been removed before the first use.


Please also confirm:

- ◆ The air inlet and outlet are completely unobstructed;
- ◆ Strainer and bottom cover are installed correctly (see as below);
- ◆ If the bottom cover is not installed properly, the device will not work properly.
- ◆ Instructions for removing the filter packaging and replacing the filter after the first use(see as below pic 1 - 6).


BEFORE USE 8




When not charging, press the power button to power off.




Rotate the bottom cover to the left, remove the bottom cover after opening the lock.




Remove the filter.



Remove the plastic bag from the new filter.



Replace the filter with the bag removed.



Put the bottom case back in its original position, rotate it to the right to align the arrow of the lock, and you can use the machine normally.

9 INSTRUCTIONS FOR USE

Power

Press the power button to turn on the purifier, the default is one gear wind speed.

Wind speed adjustment

The wind speed is in grade 1, and the wind speed indicator light is on. Press the power button again, the wind speed switches to 2, and the wind speed indicator lights up 2.

Press the power button again, the wind speed is switched to 3, and the wind speed indicator is all on. Press the power button again, the purifier is turned off and all lights are off.

Night light function

By default, the night light is turned off. Press the power button twice within 1s to turn on the night light function. Press the power button twice again quickly to turn off the night light function.

Filter reset function

when the purifier is in working condition and the filter life is 0 hours, the power light will start flashing to prompt the replacement of the filter.

INSTRUCTIONS FOR USE 10

After replacing the filter, press and hold the power button for 5S in standby mode and the power light flashes 3 times and then goes off, indicating that the filter is successfully reset and the power light is always on when the purifier is turned on again.

Timer function

Long press the power button 3S to open the 5-hour timer function, the timer indicator is always on, and the device will be automatically turn off after the time is up.

PRODUCT CONFIGURATION AND PARAMETERS

Rated voltage:	5V	Filter Lifespan:	3-6 months
Rated power:	5W	Material:	ABS
Overall size:	135*135*193mm	Product Weight:	0.8KG

11 MAINTENANCE

Before performing any maintenance operations, be sure to turn off the power and turn off the machine by pressing the button (4).

ou can use a slightly damp cloth to clean the product body

Important tips: Do not use any abrasive materials to prevent damage to the equipment surface.

Filter replacement

Filter operating frequency	Operation	Frequency
Activated carbon and HEPA	Replace	Composite filter change every 6 months

This data is calculated based on the use of low-grade purification wind speed, using 8 hours a day;

The recommended filter replacement frequency will vary depending on the duration of use and the working environment. When the filter needs to be replaced, the power light will start blinking.

Attention! When your purifier motor stops working, please check if the filter needs to be replaced.

MAINTENANCE 12

Filter life is 3600 hours. After the power is turned on, the power button light is always on, and the filter life starts counting and decreases. When the life of the filter is less than 1 hour while the air purifier works, the power light starts to flash to remind you that the filter needs to be replaced.

After replacing the filter, press and hold the power button for 5 seconds in the standby state. The power light will flash 3 times and then go out, indicating that the filter has been replaced successfully, and the filter life will start counting again. The power light will always be on when the device is turned on again.

13 MAINTENANCE

The filter indicator light is on, indicating that the activated carbon and HEPA composite filters need to be replaced;

NOTE:

*The activated carbon and HEPA filter cannot be washed or used repeatedly. Do not wash them with water.

*Replace the filters one by one, please refer to “Before Use” one by one “Instructions for removing the filter package for the first use and replacing the filter after the life of the filter has expired”.

WARM TIPS

- ◆ If you are allergic or have asthma, avoid touching the used filters;
- ◆ Wear gloves when replacing the filter, or wash your hands after replacement;
- ◆ Put the used filter in a sealed bag and throw it away to prevent the spread of pollutants.

When not using the purifier for a long time, please store it in a dry, cool place.

COMMON MALFUNCTIONS

Do not disassemble the machine without permission; improper repair may cause danger to the user!

Before contacting the after-sales service center, please check the following troubleshooting table:

Malfuction	Examination	Approach
Can not start	Is the power plugged in?	Plug in the power supply at the correct voltage.
	Are all the indicators not lit?	Press the switch button to select the desired function
	Is there a power outage?	Device available when power is restored.
	Is the rear case closed?	Install the rear case properly.

15 COMMON MALFUNCTIONS

Malfunction	Examination	Approach
Airflow is greatly weaker than before	Does the filter need to be replaced?	Check if the filter has reached the replacement cycle and replace the filter if necessary.
Odor from the air outlet	Does the filter need to be replaced?	
Wind speed cannot be changed automatically	Whether it is manual mode?	Choosing the right operating mode.

KOIOS



www.koiosshop.com



support@koiosshop.com



1-855-888-2111



m.me/KoiosShop



Made in China