ITEM NO.N715P307322

Dining Table



ITEM NO.N715P307322


Please read these instructions fully before starting assembly:

- 1. Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.
- 2. Kindly follow the assembly instructions step by step.
- 3. Do not tighten all screws and bolts until the table is fully assembled.
- 4. Unscrew the protective plastique supports from the metal insert of the table legs before assembly.
- 5. Parts of the assembly will be easier with 2 people.

Care and maintenance:


Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

ITEM NO.N715P307322



ITEM NO.N715P307322

Part List




ITEM NO.N715P307322

Hardware List


Tialuwale List			
1	2		
B	(a)		
Ø 5/16" x 45 mm	Ø 5/16" x 50 mm		
BOLT (16 pcs)	BOLT (4 pcs)		
3	4		
Ø5/16" x 13 mm	Ø5/16" x 19 x 2 mm		
LOCK WASHER (20 pcs)	FLAT WASHER (12 pcs)		
5	6		
4 mm	Ø10 x 30 mm		
ALLEN KEY (1 pc)	WOOD DOWEL (4pcs)		
	<u> </u> 5		


ITEM NO.N715P307322

STEP 1:




BOLT	LOCK WASHER	FLAT WASHER	ALLEN KEY
Ø 5/16" x 45 mm	Ø5/16" x 13 mm	Ø5/16" x 19 x 2 mm	4 mm
0	0	0	
①x 4	③x 4	4 x 4	⑤x 1





ITEM NO.N715P307322

STEP 5:



COMPLETE

