


INSTALLATION INSTRUCTION

DeerValley®

Shower Niche





Prior to Installation:

- Before installation, please make sure that the water source is closed and the water supply pipeline is reserved.
- Please confirm that the installation wall is a load-bearing wall. After completing the installation of heavy objects above 150 kgf, the wall can withstand this tensile force, and make sure that the wall is flat after installation.
- Please make sure that a qualified professional follows the steps in this manual to install.

General Recommendations:


Please read installation and maintenance instructions thoroughly before installing the wall mount bathroom sink. Be sure to use proper tools and always wear proper personal safety accessories for your protection.

**If you have any questions or concerns
please contact us:**


(+1) 312-626-9466
service@deervalleybath.com

INSTRUCTIONS

(1) SUGGESTED TOOLS AND MATERIALS



Silicon Sealant




Caulk Gun

- Sealant-We recommend the use of a stone, marble and granite silicone caulk or a general purpose silicone sealant.


WARNING:

To reduce the risk of injury or property damage, read and follow all of the installation instructions before installing this product and wear safety goggles. This product must be installed in accordance with all state and local plumbing and building codes. Call a professional if you are uncertain about installing this product properly.


(2) INSTALLATION INSTRUCTION




STEP 1: Locate the desired position. Create and level the dimensions of the wall section according to the measurement of the shower niche.



STEP 2: Apply the silicone sealant around the back flange of the shower niche. After accurately rinsing out, apply the silicone sealant to the back of the shower niche.



STEP 3: Insert the shower niche into the measured wall section in Step 1 and fix it accordingly.



STEP 4: Seal all the joints with silicone sealant by ensuring a waterproof seal. The shower niche is now ready.

(3) Cleaning and Maintenance Guide

To optimize the cleaning instructions for a Metal Niche surface while preventing damage, follow these steps:

STEP 1: Prepare Your Supplies

- Soft cotton cloth
- Mild detergent
- Dry and Clean cotton cloth
- Water

STEP 2: Prepare the Cleaning Solution

- Mix a small amount of mild detergent with water to create a gentle cleaning solution

STEP 3: Initial Surface Wipe

- Dip the soft cotton cloth into the prepared cleaning solution
- Gently wipe the Metal Niche surface, following the brushed texture pattern
- Ensure that you don't use excessive pressure to avoid scratching

STEP 4: Rinse and Repeat

- Wet a clean cotton cloth with water
- Wipe the Metal Niche surface again to remove any detergent residue

STEP 5: Dry and Shine

- Use a dry microfiber cloth to absorb any remaining moisture, leaving the surface shiny
- Ensure the surface is completely dry to prevent water spots

By following these optimized steps, you can effectively clean the Metal Niche surface while minimizing the risk of damage and maintaining its appearance.

Optimized Shower Niche Maintenance Guide:

Tips 1. Gentle Cleaning: Utilize a mild detergent and a soft microfiber cloth for cleaning and maintenance purposes.

Tips 2. Texture-Conscious Wiping: When cleaning, follow the direction of the metal texture to maintain the surface's integrity.

Tips 3. Residue Removal: After wiping, ensure thorough residue removal by using a soft cotton cloth.

Tips 4. Avoid Rusty Storage: Prevent potential surface damage by refraining from storing rusty metal containers in the niche.

Tips 5. Mindful Placement: Be aware that prolonged contact with cosmetics or other metal accessories may lead to localized corrosion in Stainless Steel Niches.

By following these optimized guidelines, you'll maintain your shower niche effectively, ensuring its longevity and appearance.

LIMITED WARRANTY COVERAGE

1 YEAR LIMITED WARRANTY

DeerValley products are made with quality materials and excellent craftsmanship to provide the customers a long-lasting product. In the case of any defects in materials or craftsmanship under regular use were inspected in the first one year of delivery, DeerValley will provide replacement parts at no charge, or at its option, replace any product or part of the product that is deemed defective, under normal installation, use, service and maintenance. This warranty applies only to the original purchaser. Proof of purchase will be required in the case of a claim. **SCRATCHES ARE NOT COVERED UNDER WARRANTY.**

The manufacturer warrants this product to be free of manufacture defects during the above mentioned warranty time. Please keep a copy of the original invoice as proof of purchase.

DeerValley will, as its option, (1) repair or replace the defective part(s) or product(s) at no charge; (2) issue a refund of the original purchase price of the product(s) (Valid within 30 days from the date of delivery); or (3) issue a credit to be applied toward the purchase of a new DeerValley product shipping/delivery charges may apply and are in DeerValley sole discretion.

DeerValley recommends the installations to be made by a licensed, professional plumber. DeerValley will not be held responsible for any damage or product failure due to improper installation, misuse, or failure to use a licensed professional. DeerValley is not responsible for any removal or installation cost.

This limited warranty shall not apply to goods which have been subject to accident, negligence, improper installation, product abuse, product misuse, or use of cleaners containing abrasives, alcohol or other organic solvents, whether performed by a contractor, service company, or yourself, are excluded from this warranty.

DeerValley responsibility under this limited warranty is limited to only to replacement parts and no other costs. DeerValley will not be responsible for labor charges and/or damage incurred by installation, repair or replacement, nor for any indirect incidental or consequential damages, losses, injury or costs of any nature relating to this product Except as provided by law, this limited warranty is in lieu of and excludes all other warranties, conditions, and guarantees, whether expressed or implied, statutory or otherwise, including without restriction those merchantability of fitness for use.

RESPONSIBILITIES OF OTHERS

Inspecting the unit prior to installation is the responsibility of the installer or building contractor who acts on behalf of the user. They are responsible for ensuring the unit is free of defect or damage.

Notices are placed on and in the unit and on the shipping carton advising the installer of this responsibility.

In the event of a problem, the unit must not be installed. DeerValley is not responsible for failures or damage that could have been discovered, repaired, or avoided by proper inspection and testing prior to installation.

Damage occurring in transit is the responsibility of the carrier. The user or installer **MUST** open the crate and inspect the unit for damage when it is delivered. If damage is discovered, it must be reported immediately to the seller and the carrier in writing, and an inspection requested. Failure of the carrier to respond should be reported to the seller and the carrier. Your freight claims should be filed promptly thereafter.

LIMITATIONS AND EXCLUSIONS

This warranty does not cover instances of negligence, misuse, abuse, improper installation, carelessness, accident, hard water or mineral deposits, exposure to corrosive materials, misapplication, damages caused by improper maintenance, alteration of the product, or failure to follow care or installation instructions enclosed with your product. The warranty becomes invalid if the DeerValley product undergoes any alterations or if attempts are made to carry out repairs using unauthorized accessories or parts from DeerValley.

DeerValley will not be liable for loss of use of the DeerValley products, inconvenience, or any other incidental or consequential costs, expense or damages. Please note that some states do not allow the exclusion or limitation of incidental damages.

DISCLAIMER

Except as expressly provided, there shall be no warranty or obligation, express or implied, oral or statutory. No dealer or other person has the authority to make any warranties or representations concerning DeerValley or its products. In no event shall DeerValley be held responsible for any such warranties or representations.

WARRANTY SERVICE

NOTE: When requesting warranty, be sure to have the following:

- Copy of original invoice
- Date of installation
- Description and pictures of defect
- Model number or description of model

To obtain warranty service and replacement part, please contact DeerValley Customer Service. DeerValley will determine whether to repair or replace your product, issue a refund, or issue a credit.

